

Copeland outdoor refrigeration units for A2L & A1 applications

ZXMY-020E to ZXMY-075E

ZXDY-030E to ZXDY-075E

ZXLY-020E to ZXLY-075E



Table of contents

About these guidelines.....	1
1 Safety instructions.....	1
1.1 Icon explanation.....	1
1.2 Safety statements.....	2
1.3 General instructions.....	2
2 Product description.....	3
2.1 General information about Copeland ZX*Y refrigeration units.....	3
2.2 EU Ecodesign Directive 2009/125/EC.....	3
2.3 Main product features and dimensions.....	4
2.4 Product nameplate.....	6
2.5 Nomenclature.....	6
2.6 Application range.....	6
2.6.1 Qualified refrigerants and oils.....	6
2.6.2 Application limits.....	6
2.6.3 PED category.....	7
2.7 BOM variations.....	7
2.8 P&I diagrams.....	8
2.8.1 ZXMY units.....	8
2.8.2 ZXDY units.....	9
2.8.3 ZXLY units.....	10
2.9 Main components description.....	11
2.9.1 Compressor.....	11
2.9.2 Condenser fan(s).....	11
2.9.3 Housing.....	11
2.10 XCM25D Electronic controller – Features.....	12
2.10.1 Description.....	12
2.10.2 Functionalities.....	12
2.10.3 Modbus communication.....	13
2.10.4 Main control & safety features.....	13
2.10.5 Additional features for customization.....	14
2.11 XCM25D Electronic controller – Programming.....	19
2.11.1 Programming the local display.....	19
2.11.2 Remote display CCM60.....	20
2.11.3 Single commands.....	20

2.11.4	Double commands – Entering programming level 1 "Pr1"	21
2.11.5	How to program the parameters (Pr1 and Pr2)	21
2.11.6	Entering programming level 2 "Pr2"	21
2.11.7	Fast access menu.....	22
2.12	Controller keyboard.....	22
2.12.1	How to lock the keyboard.....	22
2.12.2	How to unlock the keyboard.....	22
2.13	Parameters level 1 – Required settings.....	23
2.14	Digital operation.....	23
2.15	Pumpdown.....	24
2.15.1	External pumpdown without XCM25D integration (not available on ZXDY units)	24
2.15.2	Pumpdown by the unit controller (not available on ZXDY units)	24
2.15.3	Pumpdown with room thermostat (not available on ZXDY units).....	25
2.15.4	Internal pumpdown with temperature sensor (case temperature).....	25
2.16	Reset to factory settings – Copeland Controls Hot Key	27
2.16.1	How to save factory settings or user settings	27
2.16.2	Copeland Controls Hot Key for ZX*Y units with XCM25D controller.....	27
2.16.3	Location of the Hot Key plug connection on the XCM25D controller	27
2.16.4	How to program a hot key from the controller (upload).....	27
2.16.5	How to program a controller using a hot key (download).....	27
2.17	Troubleshooting – Alarm history.....	28
2.18	Compressor motor protection.....	28
2.19	System pressure protection	28
2.20	Other inputs of the XCM25D controller.....	29
2.20.1	Customer-supplied control (room thermostat)	29
2.20.2	Case temperature controller	29
2.20.3	Ambient temperature sensor.....	29
2.21	Alarm output (DO5) of the XCM25D controller	29
3	Installation.....	30
3.1	Refrigeration unit handling	30
3.1.1	Transport and storage	30
3.1.2	Weights	30
3.2	Refrigeration piping connections.....	31
3.2.1	Refrigeration piping installation	31
3.2.2	Brazing recommendations	32
3.2.3	Brazing procedure	33
3.3	Electrical connection	33

3.3.1	Power supply connections	34
3.3.2	Maximum operating currents for cable selection	36
3.3.3	Electrical protection standard (protection class)	36
3.3.4	Terminal box	36
3.3.5	Low-pressure protection	37
3.3.6	Crankcase heater	37
3.3.7	Insulation material	37
3.3.8	Vibration	37
3.3.9	High-potential testing	37
3.3.10	Circuit breaker with overcurrent protection	38
3.4	Pressure relief valve (PRV)	39
3.4.1	Pressure relief valve minimum requirements	39
3.4.2	Pressure relief valve installation	39
3.5	Location & fixings	40
4	Start-up & operation	42
4.1	Strength-pressure test	42
4.2	System tightness test	42
4.3	Evacuation	42
4.4	Charging procedure	43
4.4.1	Refrigerant charging procedure	43
4.4.2	Oil charging procedure	44
4.4.3	Oil separator	44
4.5	Rotation direction of scroll compressors	44
4.6	Maximum compressor cycle	44
4.7	Checks before starting & during operation	44
4.8	Pressure fluctuations in case of digital unit	45
4.9	Pumpdown cycle	45
5	Maintenance & repair	46
5.1	General considerations	46
5.2	Qualification of workers	46
5.3	Preparation and work procedure	46
5.4	Disassembling system components	47
5.5	Replacing a compressor	47
5.6	Exchanging the refrigerant	48
5.7	Replacing the crankcase heater	48
5.8	Electrical terminations	49
5.9	Condenser fins	49
5.10	Routine leak testing	49

5.11	Condenser fans & motors	50
6	Certification & approval	51
7	Dismantling & disposal	51
	Appendix 1: Overview of the ZX*Y unit components	52
	Appendix 2: Wiring diagram – ZXMY & ZXLY units (380-420 V / 3 Ph / 50 Hz).....	53
	Appendix 3: Wiring diagram – ZXDY units (380-420 V / 3 Ph / 50 Hz)	54
	Appendix 4: Parameters level 1	55
	Appendix 5: Alarm menu.....	56
	Appendix 6: Additional features for customization.....	60
	Appendix 7: Temperature / resistance curve for B7 Sensor (customer option).....	64
	Appendix 8: List of tables and figures	65

About these guidelines

The purpose of these application guidelines is to provide guidance in the application of Copeland ZX*Y outdoor refrigeration units. They are intended to answer the questions raised while designing, assembling and operating a system with these products.

Besides the support they provide, the instructions listed herein are also critical for the proper and safe functioning of the refrigeration units. The performance and reliability of the product may be impacted if it is not used according to these guidelines or is misused.

These application guidelines cover stationary applications only. For mobile applications, contact Application Engineering as other considerations may apply.

1 Safety instructions

Copeland refrigeration units are manufactured according to the latest European safety standards. Particular emphasis has been placed on the user's safety.

The ZX*Y outdoor refrigeration units are intended for installation in machines and systems in accordance with the following directives and regulations:

Machinery Directive MD 2006/42/EC	Supply of Machinery (Safety) Regulations 2008
Pressure Equipment Directive PED 2014/68/EU	Pressure Equipment (Safety) Regulations 2016
Low Voltage Directive LVD 2014/35/EU	Electrical Equipment (Safety) Regulations 2016
Electromagnetic Compatibility Directive EMC 2014/30/EU	Electromagnetic Compatibility Regulations 2016
Ecodesign Directive 2009/125/EC	Ecodesign for Energy-Related Products Regulations 2010









They may be put to service only if they have been installed in these systems according to instructions and conform to the corresponding provisions of legislation. For relevant standards please refer to the Manufacturer's Declaration, available at www.copeland.com/en-gb.

NOTE: Only dedicated compressors and refrigeration units are allowed to be used with flammable refrigerants. Copeland marks all compressors and units that are qualified for flammable refrigerants with a sticker indicating the usage of such refrigerants. Systems using flammable refrigerants must be executed correctly while observing safety rules, as specified in corresponding safety standards such as, but not limited to EN 378. They must comply with any and all applicable legislation and regulations. Ensuring compliance remains the user's responsibility.

These instructions should be retained throughout the lifetime of both the compressor and the refrigeration unit.

You are strongly advised to follow these safety instructions.

1.1 Icon explanation

	WARNING This icon indicates instructions to avoid personal injury and material damage.		Fire hazard This icon indicates a risk of flammable atmosphere.
	High voltage This icon indicates operations with a danger of electric shock.		CAUTION This icon indicates instructions to avoid property damage and possible personal injury.
	Danger of burning or frostbite This icon indicates operations with a danger of burning or frostbite.		IMPORTANT This icon indicates instructions to avoid malfunction of the compressor.
	Explosion hazard This icon indicates operations with a danger of explosion.	NOTE	This word indicates a recommendation for easier operation.
	Danger of explosive atmosphere This icon indicates a risk of explosive atmosphere.		

1.2 Safety statements

- Refrigerant compressors and refrigeration units must be employed only for their intended use. The system has to be labelled according to the applicable standards and legislation.
- Only qualified and authorized RACHP (refrigeration, air conditioning and heat pump) personnel are permitted to install, commission and maintain this equipment.
- Electrical connections must be made by qualified electrical personnel.
- All valid standards for connecting electrical and refrigeration equipment must be observed.
- The national legislation and regulations regarding personnel protection must be observed.

Additional requirements and statements for A2L refrigerant systems:

- Only competent personnel (as specified in EN 13313) qualified for flammable refrigerant handling are permitted to commission, initiate and maintain the compressor/refrigeration system; non-trained personnel, including the user, are not allowed to do so and must call on an expert.
- The maximum refrigerant charge is specified in standards such as, but not limited to EN 378, EN 60335-2-40 and EN 60335-2-89. The system designer shall implement all safety measures defined by the applicable standards and the maximum refrigerant charge shall not be exceeded.
- The system designer must carefully evaluate the risk of external fire. If necessary, a pressure relief valve should be installed to avoid excessive pressure due to external fire. Follow the instructions given in section 3.4 "Pressure relief valve (PRV)" for pressure relief valve selection and installation.
- If a flammable atmosphere is detected, immediately take all necessary precautions to mitigate the risk as determined in the risk assessment.



Use personal safety equipment. Safety goggles, gloves, protective clothing, safety boots and hard hats should be worn where necessary.

1.3 General instructions



WARNING

Pressurized system! Serious personal injuries and/or system breakdown!

Accidental system start before complete set-up must be avoided. Never install a system in the field and leave it unattended when it has no charge, when it has a holding charge, or with the service valves closed, without locking out the system electrically.



WARNING

System breakdown! Personal injuries! Only approved refrigerants and refrigeration oils must be used.



WARNING

High shell temperature! Burning! Do not touch the compressor or piping until they have cooled down. Ensure that other materials in the area of the compressor do not come into contact with it. Mark and secure accessible sections.



CAUTION

Overheating! Bearing damage! Do not operate compressors without refrigerant charge or without being connected to the system.



CAUTION

Contact with refrigerant oil! Material damage! Polyolester oil (POE) must be handled carefully and the proper protective equipment (gloves, eye protection, etc.) must be used at all times. POE must not come into contact with any surface or material that it might damage, including without limitation, certain polymers, eg, PVC/CPVC and polycarbonate.



IMPORTANT

Transit damage! Unit malfunction! Use original packaging. Avoid collisions and tilting.



IMPORTANT

This appliance is not designed to be accessible to the general public according to IEC 60335-2-40.

The contractor is responsible for the installation of the unit and should check the following points:

- sufficient liquid sub-cooling in the line to the expansion valve(s) to avoid "flash-gas" in the liquid line;
- sufficient amount of oil in the compressor (in case of long piping additional oil must be charged).

2 Product description

2.1 General information about Copeland ZX*Y refrigeration units

Copeland has developed the ZX*Y outdoor refrigeration unit to meet primarily the demands of the food retail and food service sectors. It is a refrigeration air-cooled refrigeration unit that uses the latest Copeland patented scroll technology as the main driver and has electronic protection and diagnostics features built in the compact chassis. The combination of large condensers and low-speed fans allows for particularly quiet operation.



2.2 EU Ecodesign Directive 2009/125/EC

The European Directive 2009/125/EC with regard to Ecodesign requirements for professional refrigerated storage cabinets, blast cabinets, refrigeration units and process chillers requires manufacturers to decrease the energy consumption of their products by establishing minimum energy efficiency standards. Copeland refrigeration units are prepared and optimized to meet the requirements of the Ecodesign Directive. The integrated variable speed fan and condenser reduce the noise level and energy consumption significantly. This, combined with Copeland scroll technology, allows for high-efficiency operation.

For the rated cooling capacity, rated power input and rated COP value please refer to Copeland Select software at www.copeland.com/en-gb.

These guidelines meet the requirements of Regulation 2015/1095, Annex V, section 2(a), with regard to product information, namely:

- (v) → See chapter 2.6 "Application range"
- (vi) → See chapters 5.9 "Condenser fins" and 5.10 "Routine leak testing"
- (vii) → See chapters 2.10.4 "Main control & safety features" and 4.4 "Charging procedure"
- (viii) → See chapter 7 "Dismantling & disposal"

2.3 Main product features and dimensions

Copeland ZX*Y refrigeration units are released for multiple refrigerants. They are available in two cabinet sizes and are equipped with one or two fans. These units are designed for medium- and low-temperature refrigeration applications.

Unit	Refrigerant	Displacement @ 50 Hz (m ³ /h)	Cooling capacity* (kW)	Nominal power (kW)	Rated current (A)	PS high side (bar)	PS low side (bar)	
Medium temperature standard units								
ZXMY-020E	R454A, R454C, R455A, R1234yf, R513A, R134a, R448A, R449A, R404A, R450A, R507A, R407A, R407C, R407F	5.76	3.05	1.39	5.21	28	22	
ZXMY-030E		8.00	4.23	1.84	6.51			
ZXMY-040E		11.40	5.94	2.64	8.81			
ZXMY-050E		14.30	7.53	3.26	11.62			
ZXMY-060E		16.70	8.77	3.85	13.32			
ZXMY-075E		21.40	10.90	4.99	17.42			21
Medium temperature digital units								
ZXDY-030E	R454A, R454C, R455A, R1234yf, R513A, R134a, R448A, R449A, R404A, R450A, R507A, R407A, R407C, R407F	8.81	4.55	2.08	7.71	28	22	
ZXDY-040E		11.40	6.10	2.67	11.52			
ZXDY-050E		14.40	7.56	3.29	12.82			
ZXDY-060E		17.10	8.92	3.94	13.82			
ZXDY-075E		21.40	11.00	4.92	17.42			21
Low temperature standard units								
ZXLY-020E	R454A, R454C, R455A	5.92	1.04	0.98	6.20	28	21	
ZXLY-030E		8.03	1.40	1.36	7.20			
ZXLY-040E		11.75	2.01	1.99	9.20			
ZXLY-050E		14.37	2.59	2.23	11.20			
ZXLY-060E		17.06	3.04	2.68	13.70			
ZXLY-075E		21.39	3.78	3.33	17.20			

* Conditions for ZX*Y using R454C: evaporating temp = -10 °C (-35 °C for ZXLY), ambient temp = 32 °C, suction temp = 20 °C.

Table 1: ZX*Y refrigeration unit technical data

Unit	Outer dimensions length/width/height with closed cover (mm)	Net weight (kg)	Number of fans	Liquid receiver size (litres)
Medium temperature standard units				
ZXMY-020E	424 / 1027 / 840	73	1	4.1
ZXMY-030E		80		
ZXMY-040E		86		
ZXMY-050E	424 / 1029 / 1244	112	2	5.9
ZXMY-060E		114		
ZXMY-075E		116		
Medium temperature digital units				
ZXDY-030E	424 / 1027 / 840	85	1	4.1
ZXDY-040E	424 / 1029 / 1244	106	2	5.9
ZXDY-050E		118		
ZXDY-060E		120		
ZXDY-075E		122		
Low temperature standard units				
ZXLY-020E	424 / 1027 / 840	78	1	3.9
ZXLY-030E		81		
ZXLY-040E		93		
ZXLY-050E	424 / 1029 / 1244	110	2	5.9
ZXLY-060E		114		
ZXLY-075E		120		

Table 2: ZX*Y refrigeration unit features

The figures hereafter show the overall physical dimensions of the ZX*Y refrigeration units in millimetres:




Figure 1: Dimensions of models ZXMY-020E to ZXMY-040E, ZXDY-030E and ZXLY-020E to ZXLY-040E (single-fan units)




Figure 2: Dimensions of models ZXMY-050E to ZXMY-075E, ZXDY-040E to ZXDY-075E and ZXLY-050E to ZXLY-075E (dual-fan units)

2.4 Product nameplate

The refrigeration unit nameplate shows model designation and serial number, as well as locked rotor amps, maximum rated current, safety pressures and weight.

The compressor has its own nameplate with all electrical characteristics.

2.5 Nomenclature

The model designation contains the following technical information about the refrigeration unit:




Figure 3: Nomenclature ZX*Y units

2.6 Application range

2.6.1 Qualified refrigerants and oils

Qualified refrigerants	R454A, R454C, R455A, R1234yf*, R513A*, R134a*, R448A*, R449A*, R404A*, R450A*, R507A*, R407C*, R407A*, R407F* (* = not for ZXLY)							
Qualified servicing oils	Emkarate RL 32 3MAF Mobil EAL Arctic 22CC							
Unit	ZXMY-020E	ZXMY-030E ZXDY-030E	ZXDY-040E	ZXLY-020E	ZXLY-030E	ZXDY-050E ZXDY-060E ZXDY-075E	ZXMY-040E ZXMY-050E ZXMY-060E ZXMY-075E	ZXLY-040E ZXLY-050E ZXLY-060E ZXLY-075E
Oil charge (litres)	1	1.1	1.24	1.30	1.51	1.77	1.85	1.89

Table 3: Qualified refrigerants and oils

NOTE: R454A, R454C, R455A and R1234yf are classified as A2L (mildly flammable) refrigerants.

NOTE: R513A, R134a, R448A, R449A, R404A, R450A, R507A, R407C, R407A and R407F are classified as A1 refrigerants. In order to apply these refrigerants, the approval of the Application Engineering department at Copeland is required.

NOTE: Some unit models are equipped with an oil separator – see section 2.7 "2.7BOM variations". The separator is pre-charged with 0.5 litre of oil.

2.6.2 Application limits

For application envelopes, please refer to the compressor application envelopes which can be found in Copeland Select software, available at www.copeland.com/en-gb.

ZX*Y refrigeration units can be used at ambient temperatures from -15 to 45 °C. For lower ambient temperatures please contact your local Application Engineering representative.

2.6.3 PED category

The nameplate of the unit contains information about the maximum allowable pressure PS, the minimum and maximum allowed temperatures TS, the internal free volume and the fluid groups of the refrigerants qualified for the unit model range. Values are given for both pressure ranges on low- and high-pressure sides.

The PED category is assigned according to the Pressure Equipment Directive PED 2014/68/EU. Requirements apply to the relevant pressure levels in the unit when the product of "pressure relative to the environment" by "related internal free volume" (PxV) exceeds given limits. When calculating the PED category, the high- and low-pressure sides have to be calculated separately. The highest of the calculation results is considered.

The PED category also depends on the fluid group of the qualified refrigerants, also shown on the nameplate. A distinction is made between refrigerants of fluid group 1 (flammable) and fluid group 2 (non-flammable). ZX*Y refrigeration units can be operated with both A1 (fluid group 2) and A2L (fluid group 1) refrigerants. As a result, identical unit models may be subject to different PED categories depending on the refrigerant used.

Refrigeration range	unit	Refrigerant	Fluid group	PED class
ZX*Y		R454A, R454C, R455A, R1234yf	1	II
		R513A, R134a, R448A, R449A, R404A, R450A, R507A, R407C, R407A, R407F	2	I

Table 4: PED category based on refrigerant used

2.7 BOM variations

The BOM (bill of material) number at the end of the unit designation indicates the different unit layouts and details. The ZX*Y units covered in these guidelines are available in the following BOM versions:

BOM	Family	Introduction date	Controller concept	Oil separator	Suction accumulator
304	ZXMY-020E to ZXMY-060E	10/2020	XCM25D (Copeland controls)	No	No
	ZXMY-075E	10/2020		No	Yes
454	ZXDY-030E to ZXDY-060E	10/2020		Yes	No
	ZXDY-075E	10/2020		Yes	Yes
	ZXLY-020E to ZXLY-075E	09/2021		Yes	Yes

Table 5: BOM

2.8 P&I diagrams

2.8.1 ZXMY units




Figure 4: P&I diagram for ZXMY units

Position	Description	Comments	Fast access menu
1	High-efficiency Copeland scroll compressor		
2	Service valve, liquid line		
3	Service valve, suction line		
4	Condenser with 1 or 2 fans		
5	Liquid receiver		
6	Filter-dryer		
7	Sight glass		
8 (PT)	Suction pressure transducer	Compressor setpoint	P1P
9 (PT)	Pressure transducer, high pressure	Fan speed control	P2P
10 (PSH)	High pressure limiter	System safety	
11	Tube		
12	Tube		
13	Reducer		
14	Reducer		
15	Pressure relief valve port	3/8" NPT	
16	Suction accumulator		
TZAH	Discharge temperature sensor	Compressor safety	P3t
TI	Ambient temperature sensor	Additional functions	P6t

Table 6: Legend of the P&I diagram for ZXMY units

2.8.2 ZXDY units




Figure 5: P&I diagram for ZXDY units

Position	Description	Comments	Fast access menu
1	High-efficiency Copeland scroll compressor (YBD* for digital)		
2	Service valve, liquid line		
3	Service valve, suction line		
4	Digital solenoid Y1		
5	Oil separator	Pre-charged with 0.5 L	
6	Condenser with 1 or 2 fans		
7	Liquid receiver		
8	Filter-dryer		
9	Sight glass		
10 (PT)	Suction pressure transducer	Compressor setpoint	P1P
11 (PT)	Pressure transducer, high pressure	Fan speed control	P2P
12 (PSH)	High pressure limiter	System safety	
13	Tube		
14	Tube		
15	Oil return line		
16	Tube		
17	Reducer		
18	Check valve		
19	Reducer		
20	Pressure relief valve port	3/8" NPT	
21	Suction accumulator		
TZAH	Discharge temperature sensor	Compressor safety	P3t
TI	Ambient temperature sensor	Additional functions	P6t

Table 7: Legend of the P&I diagram for ZXDY units

2.8.3 ZXLY units




Figure 6: P&I diagram for ZXLY units

Position	Description	Comments	Fast access menu
1	High-efficiency Copeland scroll compressor		
2	Service valve, liquid line		
3	Service valve, suction line		
4	Suction accumulator		
5	Oil separator	Pre-charged with 0.5 l	
6	Condenser with 1 or 2 fans		
7	Liquid receiver		
8	Filter-dryer		
9	Sight glass		
10 (PT)	Suction pressure transducer	Compressor setpoint	P1P
11 (PT)	Pressure transducer, high pressure	Fan speed control	P2P
12 (PSH)	High pressure limiter	System safety	
13	Tube		
14	Tube		
15	Oil return line		
16	Liquid injection line		
17	Reducer		
18	Thermostatic expansion valve		
19	Reducer		
20	Pressure relief valve port	3/8" NPT	
TZA	Discharge temperature sensor	Compressor safety	P3t
TI	Ambient temperature sensor	Additional functions	P6t

Table 8: Legend of the P&I diagram for ZXLY units

2.9 Main components description

2.9.1 Compressor

Medium temperature		Low temperature	
Unit model	Compressor model	Unit model	Compressor model
Standard			
ZXMY-020E	YB12K1E-TFM/TFD	ZXLY-020E	YF05K1E-TFD
ZXMY-030E	YB17K1E-TFM/TFD	ZXLY-030E	YF07K1E-TFD
ZXMY-040E	YB24K1E-TFM/TFD	ZXLY-040E	YF10K1E-TFD
ZXMY-050E	YB31K1E-TFM/TFD	ZXLY-050E	YF13K1E-TFD
ZXMY-060E	YB36K1E-TFM/TFD	ZXLY-060E	YF15K1E-TFD
ZXMY-075E	YB45K1E-TFM/TFD	ZXLY-075E	YF19K1E-TFD
Digital			
ZXDY-030E	YBD17K1E-TFM/TFD		
ZXDY-040E	YBD24K1E-TFM/TFD		
ZXDY-050E	YBD31K1E-TFM/TFD		
ZXDY-060E	YBD36K1E-TFM/TFD		
ZXDY-075E	YBD45K1E-TFM/TFD		

Table 9: Compressor models cross reference

2.9.2 Condenser fan(s)

The condensers of the ZX*Y refrigeration units are equipped with single-phase fans.

Refrigeration units			Number of fans	Fan speed	Diameter	Voltage	Power input
Medium temp. Standard	Medium temp. Digital	Low temp. Standard					
ZXMY-020E		ZXLY-020E	1	830 rpm	450 mm	380 - 420 V 1 Ph 50 Hz	115 W
ZXMY-030E	ZXDY-030E	ZXLY-030E					
ZXMY-040E		ZXLY-040E					
	ZXDY-040E		2	830 rpm	450 mm	380 - 420 V 1 Ph 50 Hz	230 W
ZXMY-050E	ZXDY-050E	ZXLY-050E					
ZXMY-060E	ZXDY-060E	ZXLY-060E					
ZXMY-075E	ZXDY-075E	ZXLY-075E					

Table 10: Condenser fans technical data

2.9.3 Housing

ZX*Y refrigeration units have specific housing features:

- Controller-window in the cabinet door. The window is IP54. It shows the current value of the electronic controller.
- The main power switch is installed on the cabinet door and allows to de-energize the unit without opening the cabinet door. To open the door the main power switch must be in off position.
- The quick-locks allow for easy and quick opening of the cabinet door by means of the cabinet key.
- The cabinet key is delivered with the unit. It is attached to one of the piping connections by means of a cable strap.

The housing is designed to withstand a 300 hour salt spray test according to ASTM B-117, ASTM D-1654 and ČSN EN ISO 9227.

Figure 7: ZX*Y unit housing



NOTE: For detailed information about unit components and spare parts, please refer to the compressor application guidelines and to the Copeland Spare Parts Catalogue available at www.copeland.com/en-gb.

2.10 XCM25D Electronic controller – Features

The XCM25D controller is designed to be a powerful, flexible controller for use in multiple applications. It has been developed for refrigeration units and allows the adjustment of all relevant parameters by the user.



Figure 8: XCM25D Electronic controller

2.10.1 Description



WARNING

Electrical pins under voltage! Electrical shock hazard! There are unused fast-on pins (C1 & DO2) on the XCM25D which could be under voltage. They are covered by insulated fast-on flags in the factory. Handle carefully when removing insulating flags during service on site.

The controller is designed for usage in an outdoor refrigeration unit. It is rated to be used in the following environment:

- Outdoor ambient temperature for controller operation: -40 to +60 °C
- Ambient temperature for storage: -40 to +80 °C
- Maximum humidity: 90 % at 48 °C (non-condensing)
- Board power: 24 V AC +15 % / -20 %
- Voltage sensing capabilities: three-phase 200-240, 380-460, 575 V AC ± 10 %

The units of measure are selectable. The factory default unit is bar (always considered relative) for pressure and °C for temperature.

2.10.2 Functionalities

The controller allows for easy commissioning by the technician with the factory settings at the highest program level. It also offers the possibility to make substantial changes to the system optimization in further programming levels. Advanced functionalities can also be activated.

The following functions are covered by the controller:

- refrigeration unit control;
- case control;
- condenser fan control;
- defrost;
- voltage and current sensing (compressor protection);
- system EXV control;
- digital compressor control;
- Modbus/Canbus communication.

NOTE: The XCM25D controller includes all the functions necessary for the control of the ZX*Y units. For additional functionalities please contact your local Application Engineering representative.




Figure 9: XCM25D controller functionality overview

2.10.3 Modbus communication

The XCM25D controller can communicate via Modbus (RS-485) connection to provide all running data. Additional commands can also be activated through Modbus connection. The Modbus map is available on request from the Application Engineering department at Copeland.

A pre-configured X-Web Supervisor device is also available and allows easy handling and connectivity with the XCM25D controller.




Figure 10: Modbus port and termination jumpers

NOTE: If the XCM25D controller is connected in chain the termination jumpers must be removed.

2.10.4 Main control & safety features

Suction pressure control: Each unit is equipped with a suction pressure transmitter. The XCM25D controls the suction pressure by evaluating the input signal of the pressure transmitter. When using a digital unit (ZXDY), the setpoint (**C16**) and proportional band (**C17**) need to be adjusted. The suction pressure regulation for ZXMY units has to be defined by compressor cut-in (**C01**) and cut-out (**C02**) values. The signal of the suction pressure transmitter is also used for additional functionalities, pumpdown and keeping the compressor running within the approved envelopes.

Condensing pressure control: Each unit is equipped with a high-pressure transmitter. The XCM25D controls the condensing pressure by regulating the fan speed corresponding to the high-pressure transmitter signal. The unit controller can regulate the condensing pressure in two ways. The first approach is to keep a constant condensing temperature. This mode is utilized by the factory settings. The pre-adjusted setpoint is 27 °C as a universal setting. If lower condensing pressure is required set up the condenser setpoint (**E39**) to a lower value. The second control way is fan modulation based on compressor envelope. This mode of setpoint control is only available if a suction pressure input is not used. The parameter (**E38**) enables/disables the mode as needed. If this function is unused, the condensing temperature setpoint will be set as a parameter (**E39**) value. The compressor is allowed to run different minimum condensing temperatures based on the suction pressure of the compressor. This is the most energy efficient way to minimize the condensing temperature as much as possible.

Compressor phase reversal: Ensures that the compressor keeps running in one direction only (clockwise = right rotation) – necessary for a compliant scroll compressor to compress and pump refrigerant. Reset is automatic once the phase rotation is correct for the compressor.

Motor current overload protection: This feature eliminates the need for external current protection for the compressor motor.

Fixed high-pressure switch: This is a non-adjustable protection device designed to prevent the compressor from operating outside of its safe high-pressure range. Reset is automatic for a set number of trips (7) then the unit will lock out and require manual restart. This feature is important to prevent the unit from cycling under these controls for a long period of time.

- ZXMY units: 28 bar cut-out / 22 bar cut-in.
- ZXDY units: 28 bar cut-out / 22 bar cut-in.
- ZXLY units: 28 bar cut-out / 22 bar cut-in.

Adjustable high-pressure limitation: The unit controller provides the possibility to stop the unit at a required discharge pressure which is lower than the cut-out value of the fixed high-pressure switch. Detailed instructions can be found in **section 2.10.5 "Additional features for customization"** hereunder.

Discharge temperature protection: Each unit is equipped with a discharge line sensor (NTC). The XCM25D controller will stop the compressor if discharge temperatures reach unacceptable levels.

Adjustable low-pressure alarm: The unit controller features an adjustable low-pressure alarm managed by the suction pressure sensor. The factory setting of this alarm is the lowest permitted pressure of the refrigerant with the lowest pressure-vapour properties. If needed the user can modify this value according to the required application.

- ZXMY units: 0.5 bar rel
- ZXDY units: 0.5 bar rel
- ZXLY units: 0.5 bar rel

A crankcase heater is connected directly to the controller. The crankcase heater will be energized when the ambient sensor is below a given value (10 °C) and the compressor has been off for a defined period of time (5 minutes). The minimum off time does not apply at initial power up.

In addition to the above, the ZX*Y refrigeration unit has the following features:

- Liquid line assembly (filter-dryer and sight glass/moisture indicator)
- Anti-corrosion treatment to the condenser fins

The electronic controller is also the base controller for the connection of many optional and customer-supplied functions such as:

- Main load controller (or thermostat)
- Electric defrost heater contactor
- Evaporator fan contactor
- Superheat controller for one electronic expansion device

2.10.5 Additional features for customization

A lot of additional features are provided by the XCM25D controller. In the European design of the electrical panel a few of the additional functionalities are prearranged and can easily be installed by connecting additional hardware to the electrical terminals. The tables in **Appendix 6** show the parameters that have to be changed in case a special feature of the controller should be activated. The tables do not show the required settings which have to be done by the system operator, eg, choosing correct setpoints for different components and different applications.

Component	Description	Prearranged terminals / Wiring diagram
Y3	Solenoid valve liquid line (not available on ZXDY units)	Terminals: X1.N / X1.8
S3	Room thermostat for pumpdown or direct control	Terminals: X1.9 / X1.10
Alarm contact	Sensor for evaporator or room	Terminals: X1.11 / X1.12
Sensor B7	Sensor for evaporator or room (NTC 10 kΩ)	Terminals: X1.13 / X1.14

Table 11: Pre-arranged additional connections

NOTE: After programming an additional function, the system will have to be restarted. To engage system restart, switch off the main power supply, wait for 5 seconds and switch it on again.




Figure 11: Pre-arranged additional connections

NOTE: Depending on the required functionalities additional components might be necessary. Please contact your local Application Engineering representative.

NOTE: Check the current limitations given by the controller relays.

NOTE: The solenoid valve function is not available on ZXDY units.

Digital output	Specifications
DO1, DO2 and DO3	Relay SPDT 16 A, 250 VAC
DO3	Relay SPST 8 A, 250 VAC
DO4 and DO5	Relay SPST 5 A, 250 VAC

Table 12: Digital output specifications

Temperature control by means of an external room thermostat (not available on ZXDY units)

The temperature of a cold room or cooling cabinet can be controlled by means of an external room thermostat (Digital Input DI3, parameter R07). The parameters that must be changed to do this are listed in Table 13 below.

Parameter	Description	Factory settings	Recommended settings / Comments
C05	Compressor regulation probe selection	1 = Suction pressure probe = SuP	Suction pressure switch / Room thermostat input = 3 = dIS
G56	Use the liquid line solenoid	NO	NO >> If a solenoid is used in the liquid line, see section 2.15 "Pumpdown" for parameter settings
R07	Digital Input function	0 = Not used = nu	Suction pressure switch / Room thermostat input = 1 = SuS
R08	Digital Input polarity	1 = Closed = CL	1 = Closed = CL (no change)

Table 13: External room thermostat – Parameters

With these settings the controller will switch the compressor according to the status of the connected device (room thermostat):

- if the input is closed, turn the compressor on (On-Off-compressor);
- if the input is open, turn the compressor off (On-Off-compressor).

Temperature control by means of an external temperature probe (not recommended for ZXDY units)

The temperature of a cold room or cooling cabinet can be controlled by means of an additional temperature (Analog Input AI7, component B7 in wiring diagram) probe (NTC, 10 kΩ – for detailed temperature/resistance curve, see **Appendix 7**). The probe can be located in the evaporator or in the room. The location of the probe has to be considered for the configuration of the **A19** setting. Based on the value provided by the **B7**-temperature sensor the compressor will be switched on and off according to the following graphics:




Figure 12: External temperature sensor – Functionality

The following parameters must be adjusted to control a cooling cabinet or a cold room with a temperature sensor:

Parameter	Description	Factory settings / Range	Recommended settings / Comments
A19	Probe configuration	7 0 = Not used = nu	Thermostat temp (NTC 10 K) = 2 = tnt or Evaporator temp (NTC 10 K) = 5 = EPt
C05	Compressor regulation probe selection	1 = Suction pressure probe = SuP	Case temperature = 2 = CSt
G01	Case temperature probe selection	0 = Not used = nu	Thermostat temperature = 4 = tnt or Evaporator temperature = 5 = EPt
G02	Setpoint case temperature	2 °C	Choose setpoint according to requirements of cooled goods
G03	Position differential case temperature	1 K 0.1 to 25.5 K	Setpoint G02 + positive differential G03 results in cut-out value for compressor
G04	Case temperature lower limit G02	-10 °C -40 to G05 °C	Define limits to avoid wrong settings for G02
G05	Case temperature upper limit G02	+15 °C G04 to 110 °C	Define limits to avoid wrong settings for G02
G06	Emergency run on-time	2 min 0 to 255 min	In case of probe failure, the compressor will cycle for a time defined by G06 & G07
G07	Emergency run off-time	1 min 0 to 255 min	In case of probe failure, the compressor will cycle for a time defined by G06 & G07

Table 14: External temperature sensor – Parameters

Please check that **G56** is set to "**NO**", ie, "no solenoid valve in the liquid line". Also check that no additional digital inputs are configured (Digital Input DI3; parameter R07 has to be set to "not used" = nu = 0).

Adjustable discharge pressure limitation

The controller has dedicated parameters to provide the possibility of adjustable discharge pressure cut-out.

Parameter	Description	Factory settings	Recommended settings
E58	Condenser temperature / Pressure threshold for high alarm	22.3 bar	Required value
E61	Condenser temperature / Pressure threshold for alarm recovery	18.3 bar	Required value

Table 15: Discharge pressure limitations

Low ambient operation

Very low ambient temperatures can result in malfunction of expansion devices because of insufficient pressure difference. Therefore, pressure cut-out during system start-up can occur. For proper operation of the expansion devices, the unit running time must allow to build up sufficient condensing pressure.

At low ambient conditions, the compressor will need to run for a minimum period of time to allow the system pressures to stabilize. If the unit operates below a defined ambient temperature (ambient temp. < **C12**) or if the ambient sensor has failed, the compressor should run for a set period of time (**C14**) when it is started based on a low suction reading.

The unit will be turned on for the minimum run time in the following cases:

- a room thermostat input is closed;
- the case temperature cut-in setting is reached;
- the low-pressure input is closed.

The unit will start in any of these cases even if parameter **G56** is set to true, ie, the thermostat or case temperature controls the liquid line solenoid.

If the pressure drops below the cut-out value or the low-pressure input opens, the unit should continue to run for the remaining minimum on time (**C14**) or until a satisfactory condenser pressure is reached (**C13**).

If a suction pressure transducer is present and the suction pressure falls below a given value (**C15**) during the minimum on time (**C14**), then the compressor is switched off without considering the minimum compressor running time in order to avoid deep vacuum operation. Parameter (**C15**) is thus the last protection parameter.

Defrost

The XCM25D is able to control defrost on evaporators. The controller can handle electrical defrost or natural / fan defrost (select with parameter **G17**). The defrost probe (parameter **G12**) provides the XCM25D with information about the temperatures in the evaporator.

The intervals between defrost cycles are controlled by parameter **G23**. This can be done based on the integrated real-time clock or by fixed intervals.

The following parameters must be adjusted to control defrost in a cooling cabinet or a cold room:

Parameter	Description	Factory settings / Range	Recommended settings / Comments
A19	Probe 7 configuration	0 = Not used = nu	Evaporator temp (NTC 10 K) = 5 = EPt
G12	Defrost probe selection	0 = Not used = nu	5 = Evaporator temperature sensor = EPt
G17*	Defrost type	0 = Electrical = EL	0 = Electrical = EL; 1 = Hot gas defrost = In (not available on ZX*Y units); 2 = Natural defrost (pulse defrost) = PLS
G18	Interval between defrost cycles	4 hours	0 to 120 hours; adjust to individual requirements
G19	Maximum duration of defrost	20 minutes	0 to 255 minutes; adjust to individual requirements
G20	Duration of pulse defrost	15 minutes	0 to G19
G21	Defrost termination temperature	10 °C	-40 to +110 °C
G22	Defrost delay time	15 minutes	0 to 255 minutes
G23**	Defrost interval mode	0 = Not used = nu	0 = nu = Not used; 1 = In = Interval; 2 = rtC = Real time clock
G24***	Display during defrost	DEFROST "dEF"	0 = dEF = Defrost; 1 = Set = Case temperature setpoint; 2 = It = Case temperature value; 3 = rt = Standard operation
G25	Maximum display delay after defrost	0 minute	0 to 255 minutes
G26	Drip time	1 minute	0 to 120 minutes
G27	Defrost at power-on	0 = NO	Avoids defrost after initial power up. If "YES", the controller will decide on defrost-related parameters if a defrost sequence is required after initial start-up.

Parameter	Description	Factory settings / Range	Recommended settings / Comments
G28	Workday defrost start 1	00:00	00:00 – 23:50 or nu = Not used
G29	Workday defrost start 2	04:00	00:00 – 23:50 or nu = Not used
G30	Workday defrost start 3	08:00	00:00 – 23:50 or nu = Not used
G31	Workday defrost start 4	12:00	00:00 – 23:50 or nu = Not used
G32	Workday defrost start 5	16:00	00:00 – 23:50 or nu = Not used
G33	Workday defrost start 6	20:00	00:00 – 23:50 or nu = Not used
G34	Holiday defrost start 1	00:00	00:00 – 23:50 or nu = Not used
G35	Holiday defrost start 2	04:00	00:00 – 23:50 or nu = Not used
G36	Holiday defrost start 3	08:00	00:00 – 23:50 or nu = Not used
G37	Holiday defrost start 4	12:00	00:00 – 23:50 or nu = Not used
G38	Holiday defrost start 5	16:00	00:00 – 23:50 or nu = Not used
G39	Holiday defrost start 6	20:00	00:00 – 23:50 or nu = Not used
G40	First weekly holiday	SUN = Sunday	0 = SUN; 1 = MON; 2 = TUE; 3 = WED; 4 = THU; 5 = FRI; 6 = SAT; 7 = nu = Not used
G41	Second weekly holiday	SUN = Sunday	0 = SUN; 1 = MON; 2 = TUE; 3 = WED; 4 = THU; 5 = FRI; 6 = SAT; 7 = nu = Not used
G42****	Fan operating mode	0 = cn = Stopped during defrost	0 = cn; 1 = On; 2 = cy; 3 = Oy
G43	Fan stop temperature	0 °C	-40 to +110 °C
G55	Fan delay after defrost / drip time	1 minute	0 to 255 minutes
S05	Relay output 2 configuration	0 = Not used = nu	6 = Defrost = dEF

Table 16: Defrost parameters

* G17 parameter >> Two defrost modes are available:

- G17 = EL → Defrost through electrical heater Compressor off
- G17 = pulse → Pulse / natural defrost Compressor off

** G23 parameter >> Defrost interval mode:

- G23 = nu (0) → Defrost functionality not used
- G23 = In (1) → Defrost in intervals G18
- G23 = rtC (2) → Enables defrost for rtC (real time clock), allows timing of defrost cycles with G28 – G41

*** G24 parameter >> Display during defrost:

- G24 = dEF (0) → Display shows "dEF" for defrost
- G24 = SET (1) → Display shows "G02" parameter value = Case temperature setpoint
- G24 = It (2) → Display shows display case temperature value
- G24 = rt (3) → Display will stay in standard operation

**** G42 parameter >> Evaporator fans function:

- G42 = cn (0) → Will switch on and off with the compressor, off during defrost
- G42 = On (1) → Fans on, even if the compressor is off, off during defrost; after defrost, there is a timed fan delay allowing for drip time, set via the "G55" parameter.
- G42 = cy (2) → Fans will switch on and off with the compressor (on during defrost)
- G42 = Oy (3) → Fans will run continuously also during defrost

Manual defrost

Please check settings for evaporator fans. The XCM25D controller can also control the evaporator fans during manual defrost.

NOTE: For additional features please contact your local Application Engineering representative.

2.11 XCM25D Electronic controller – Programming



CAUTION

Low refrigerant charge! Compressor damage! Never energize the unit/controller without minimum refrigerant system charge. There is a risk of malfunction of the controller in deep vacuum operation which can cause compressor damage.

2.11.1 Programming the local display



Figure 13: Local display

LED	Mode	Function
	On	Compressor 1 enabled
	Flashing	Anti-short cycle delay enabled
	On	Condensing fans enabled
	On	Display in bar
	Flashing	Programming mode
	On	Display in PSI
	Flashing	Programming mode
	On	When browsing the service menu
	Flashing	In fast access menu
	On	When browsing the alarm menu
	Flashing	A new alarm occurred
	On	An alarm is occurring
	On	Digital unloader solenoid on
	On	In defrost
	On	Evaporator fans - Liquid line solenoid valve on

Table 17: LED functions description

NOTE: By default, the local display will show the value of the suction pressure during operation. This can be changed by choosing another value for parameter B03 (Remote Display visualization).

Setting for B03	Value shown on the display	Comments
0	P1 value = Suction pressure	
1	P2 value = Mid-coil temperature (condenser)	
2	P3 value = Discharge line temperature	
3	P4 value = Vapour inlet EVI	Not used
4	P5 value = Vapour outlet EVI	Not used
5	P6 value = Ambient temperature	
6	P7 value = Not used in factory setting	
7	PEr value = Probe error	
8	Aou value = Analog output	

Table 18: Display visualisation

2.11.2 Remote display CCM60

This device allows for remote monitoring and control of the XCM25D controller via cable. The CCM60 has the same interface as the XCM25D controller therefore the commands and symbols are identical. The remote display shall be mounted on a vertical panel, in a 29 x 71 mm hole, and secured using the special bracket supplied – see **Figure 14**.

The temperature range allowed for correct operation is 0 to +60 °C.

Avoid places subject to strong vibrations, corrosive gases, excessive dirt or humidity. Allow for air to circulate through the cooling holes.

When front-mounted, the remote display is IP65 rated.




Figure 14: Remote display front panel mounting

The remote display is a proprietary bus of communication for Copeland Controls HMI (x-rep, CCM60) interfaces. There are two connection terminals on the back of the remote display (+ and -).

NOTE: Copeland recommends using a shielded cable twisted pair 2 x 0.5 mm².

The device must be connected to the VNR-terminal on the unit controller according to the polarity. **Figure 15** shows the VNR terminal on the unit controller.



Figure 15: VNR connection for the remote display

Before connecting cables make sure the power supply complies with the hardware requirements. Separate the terminal cables from the power supply cables, the outputs and the power connections.

2.11.3 Single commands






SET	Press the SET button to display the target setpoint. In programming mode, this allows to select a parameter or to confirm an operation.
	Press the RESET button and hold for 5 seconds to reset any lockouts if the current state of the controller allows for it to be reset.
	(UP) To view the fast access menu. In programming mode, this browses the parameter codes or increases the displayed value.
	(DOWN) In programming mode, this browses the parameter codes or decreases the displayed value.
	(SERVICE) To enter the service and alarm menu.
	Hold for 3 seconds to start a manual defrost or terminate an active defrost.

Table 19: Single commands

2.11.4 Double commands – Entering programming level 1 "Pr1"

	Press simultaneously for about 3 seconds to lock (PoF) or unlock (Pon) the keyboard.
	Press simultaneously to leave the programming mode or menu. On submenus rtC and EEV this combination allows to go back to the previous level.
	Press simultaneously for about 3 seconds to access the first level of programming mode.

Table 20: Double commands

The device provides 2 programming levels:

- **Pr1** with direct access
- **Pr2** protected with a password (intended for experts)

2.11.5 How to program the parameters (Pr1 and Pr2)

Access pre-program level		Press simultaneously for about 3 seconds to access the pre-programming level. The message rtC (real-time clock) appears.
Access program level		Press the Up or Down key until the message Par appears.
Access Pr1		Press the SET button to enter the program level. First parameter appears.
Select item		Select the parameter or submenu using the arrows.
Show value		Press the SET button.
Modify		Use the arrows to modify the value.
Confirm and store		Press the SET button: the value will blink for 3 seconds, then the display will show the next parameter.
EXIT		Press simultaneously to exit the programming mode, or wait for 30 seconds (MTO) without pressing any key.

Table 21: Programming level 1 parameters

When entering the programming level for the first time the display will show the **rtC** (real time clock) label.

- Press to access parameters N01/02/03/04/05 to adjust time & date. For further details, **see section 2.13 "Parameters level 1 – Required settings"**.
- Press to change from the rtC label to the Par label, in order to access the programming level 1.
- Press : the parameters of programming level 1 can be changed.

2.11.6 Entering programming level 2 "Pr2"

To enter the Pr2 programming menu:

- Press simultaneously for 3 seconds. The first parameter label will be displayed.
- Press till the **T18** label is displayed, then press the key;
- The blinking **PaS** label will be displayed; wait for a few seconds;
- The display will show "**0 - -**" with blinking 0: insert the password [**321**] using the and keys and confirming with the key.

2.11.7 Fast access menu

The fast access menu contains the list of probes and some values that are automatically evaluated by the board such as the superheat and the percentage of valve opening.

"nP" or "noP" stands for "Probe not present" or "Value not evaluated". "Err" means "Value out of range" or "Probe damaged, not connected or incorrectly configured".







Entering fast access menu		Press and release the UP arrow. The duration of the menu in case of inactivity is 3 minutes. The values that will be displayed depend on the configuration of the board.
Use the  or  arrow to select an entry, then press SET to see the value or to go on with another value.		<p>P1P: Pressure value of the P1 probe (suction pressure) P2t: Temperature value of the P2 probe (not valid) P2P: Pressure value of the P2 probe (discharge pressure) P3t: Temperature value of the P3 probe (discharge line temperature) P6t: Temperature value of the P6 probe (ambient temperature) P7t: Temperature value of the P7 probe (free) SH: Value of superheat. nA = not available oPP: Percentage of step valve opening LInJ: Status of the liquid line solenoid ("On" – "Off"). This information is available only if one relay is set as "Liquid Line Solenoid". SEtd: Value of the dynamic setpoint (condenser fan SET). This information is available only if the dynamic setpoint function is enabled. AOO: Percentage of the analog output (0-10 V or TRIAC PWM Mod.). This information is available only if the 0-10 V or TRIAC PWM Mod. is enabled. dStO: Percentage of the PWM output driving the valve of the digital scroll compressor L°t: Minimum room temperature H°t: Maximum room temperature HM: Menu tU1: Voltage reading V1 (not valid in standard configuration) tU2: Voltage reading V2 (not valid in standard configuration) tU3: Voltage reading V3 (not valid in standard configuration) tA1: Current reading I1 tA2: Current reading I2</p>
Exit		Press simultaneously or wait for the timeout of about 60 seconds



Table 22: Fast access menu

2.12 Controller keyboard

2.12.1 How to lock the keyboard

Keep the  and  keys pressed simultaneously for more than 3 seconds. The "**PoF**" message will be displayed and the keyboard will be locked. At this point it is only possible to see the setpoint or the maximum or minimum temperatures stored. If a key is pressed for more than 3 seconds, the "**PoF**" message will be displayed.

2.12.2 How to unlock the keyboard

Keep the  and  keys pressed simultaneously for more than 3 seconds, till the "**Pon**" message is displayed.

2.13 Parameters level 1 – Required settings

The XCM25D is preconfigured to reduce the required settings on job-site to a minimum. In most cases, it will not be necessary to enter programming level 2 "Pr2". **Table 23** gives an overview of the parameters available in programming level 1 "Pr1".

NOTE: When changing parameters C01, C02 and C05, a reset of the controller (interruption of power supply) is required.

Parameter	Description	Unit / range	Factory settings		
			ZXMY	ZXLY	ZXDY
C01	Compressor cut-in pressure setpoint	bar*	2.7	0.4	N/A
C02	Compressor cut-out pressure setpoint	bar*	1.1	0.1	N/A
C07	Refrigerant selection for regulation	R454A, R454C, R455A, R1234yf, R513A, R134a, R448A, R449A, R404A, R450A, R507A, R407A, R407C, R407F	R454C		
C16	Digital compressor setpoint	bar*	N/A	N/A	2.1
C17	Proportional band for compressor regulation	bar*	N/A	N/A	2.0
C21	Cycle time for digital compressor	sec	N/A	N/A	10
C24	Minimum capacity for digital compressor	%	N/A	N/A	20
C25	Maximum capacity for digital compressor	%	N/A	N/A	100
D29	Low-pressure alarm value	bar*	0.6	0.0	0.6
E39	Condenser setpoint	°C	27.0		
E46	Regulation band of variable fan	°C	10.0		
N01	Current minute	-	-		
N02	Current hour	-	-		
N03	Day of the month	-	-		
N04	Month	-	-		
N05	Year	-	-		
T18	Access to Pr2 level	-	Password: 3 2 1		

* Pressure values are always relative

Table 23: Parameters in programming level Pr1

NOTE: The full list of parameters in programming level "2" can be found in Technical Information TI_Unit_ZX_A2L_01 "Copeland ZX*Y outdoor refrigeration units for A1 & A2L applications – XCM25D Controller Parameter List".

2.14 Digital operation



WARNING

Ignition source in a potentially flammable atmosphere! Fire hazard! All electrical components, including digital solenoid valves, could be a source of ignition and must always be switched off during service and maintenance.

A digital unit is able to operate in a part-load mode. Part-load operation is achieved by loading and unloading of the digital scroll compressor for certain periods of time (time cycles). The cycle of time can be chosen between 10 and 30 seconds. Example: if the time cycle is 20 seconds at 50 % of capacity request, the compressor will run for 10 seconds loaded and 10 seconds unloaded. For proper commissioning of the digital unit the diagram in **Figure 16** must be considered.

The regulation starts when the suction pressure (AI1) increases and reaches the value $(C16-C17/2+(C17*C24)/100)$. Within the adjustment range $(C16-C17/2 \sim C16+C17/2)$ the digital scroll compressor is activated in PWM mode according to the value of the control variable.

When the pressure is higher than $(C16+C17/2)$ then the TRIAC output is at maximum capacity. When the pressure is lower than $(C16+C17/2)$ but higher than $(C16-C17/2)$ the digital compressor modulates the

capacity according to the proportional band. If the pressure is lower than (C16-C17/2) the digital compressor switches off.




Figure 16: Digital operation

NOTE: When the digital valve on the compressor is discharged the compressor is loaded.

NOTE: At start-up the valve is energized for C20 start-up time, ie, time interval with the digital valve energized before regulation starts. It ranges from 0 to 10 seconds.

2.15 Pumpdown



WARNING

Operation below atmospheric pressure! Fire hazard! Never operate the system below atmospheric pressure as a flammable mixture could form inside the system. Make sure that air does not enter the system. Use a separate A2L-dedicated recovery unit so that the compressor does not have to be used.



CAUTION

System pressure below atmospheric pressure! Compressor damage! Never operate the system below atmospheric pressure. There is a risk of malfunction of the controller in deep vacuum operation which can cause compressor damage.

Pumpdown functionality is provided by the XCM25D controller for ZXMY & ZXLY standard units only. It is not released for ZXDY digital units.

NOTE: Depending on the compressor and/or system design an increase of suction pressure is possible when the unit stops. Therefore, pumpdown operation requires higher differences between cut-in and cut-out setpoints. These values must be adjusted according to application.

2.15.1 External pumpdown without XCM25D integration (not available on ZXDY units)

The easiest solution for pumpdown is to install a solenoid valve in the liquid line (not part of the standard delivery) and to control it directly with the room thermostat or other external devices. The settings on the unit for compressor cut-in and cut-out (C01 & C02) can easily be adjusted for pumpdown. The disadvantage of this easy solution is that the controller is not informed that a solenoid valve is installed and therefore some protection features of the controller, eg, maximum pumpdown time in case of blocked solenoid, will not work.

2.15.2 Pumpdown by the unit controller (not available on ZXDY units)

In case of pumpdown by the unit controller (available only on ZXMY and ZXLY units) the user needs to install a solenoid valve in the liquid line (not part of the standard delivery). In addition to the liquid line solenoid valve a digital input signal from a room thermostat or a case temperature sensor must be connected to the XCM25D. There are additional terminals available in the unit which allow for easy connection of additional hardware if required. The wiring diagram also shows these optional features. The liquid line solenoid valve Y3 can be connected to terminals X1.N & X1.8. The terminals X1.9 & X1.10 can be used for a room thermostat (connected to DI3).

If a temperature sensor is preferred the analog input AI7 can be used (Caution: controller settings are not preconfigured for temperature sensor). For details about alternative options please see sections 2.15.3 "Pumpdown with room thermostat (not available on ZXDY units)" and 2.15.4 "Internal pumpdown with temperature sensor (case temperature)".

In any case there are limitations for the cut-out values of the compressors given by the envelopes. The minimum cut-out settings are shown in **Table 24** below. Those values are also applicable in case pumpdown is carried out by means of an additional low-pressure switch. Operation of the unit below the suction pressures shown in the table could result in tripping of the compressor internal motor protector (Klixon, error code **E28**). The envelopes are in accordance with Select software available at www.copeland.com/en-gb/tools-resources.

Unit family	R454A	R454C	R455A	R1234yf
ZXMY	1.2 bar rel	0.8 bar rel	0.9 bar rel	0.51 bar rel
ZXDY	Not approved for pumpdown			
ZXLY	0.14 bar rel	-0.09 bar rel	-0.03 bar rel	-

Table 24: Minimum cut-out value for pumpdown

NOTE: The values in the table show the lowest suction temperatures / pressures in the envelopes. Depending on the condensing temperature in the actual system it might be required to adjust / increase the cut-out value according to the approved envelope published in Select.

2.15.3 Pumpdown with room thermostat (not available on ZXDY units)

Configure parameter **C05** "Compressor regulation probe selection" to "3" (Suction pressure switch / Room thermostat input). In addition, change setting for **G56** from "0" to "1". This is information to the controller that a solenoid valve is present.

Change the functionality of Digital Input 3 (**DI3**) (Parameter **R07**) to setting 1 (Suction pressure switch / Room thermostat input) and adjust the relay output configuration **S07** to 7 (Liquid line solenoid).

Parameter	Factory settings	Pumpdown settings
C02	2 bar rel	Cut-out value for pumpdown, eg, 0.2 bar rel
C05	1 = Suction pressure probe = SuP	3 = Suction pressure switch / Room thermostat = dIS
G11	3 minutes	Maximum pumpdown time
G56	0 = No	1 = Yes
R07	0 = Not used = nu	1 = Suction pressure switch / Room thermostat = SuS
S07	0 = Not used = nu	7 = Liquid line solenoid = LLS

Table 25: Pumpdown 1

Room thermostat switch status	Liquid line solenoid valve status
Closed	Switch on / Energized
Open	Switch off / De-energized

Table 26: Pumpdown 2

For example, if the room thermostat switch is closed, the liquid line solenoid valve is activated, and the compressor will run when the suction pressure value is higher than the compressor cut-in value **C01**.

The liquid line solenoid valve will be switched off if the room thermostat switch is open and pumpdown will start. The compressor will stop once the suction pressure value is lower than the compressor cut-out value **C02** or when the pumpdown duration is longer than the maximum pumpdown time **G11** setting.

The functionality of parameter **G11** protects the cooled goods in case of component damage, eg, the liquid line solenoid is mechanically blocked and not able to stop refrigerant mass flow. In that case the compressor cut-out pressure will not be reached and the compressor will continue to run. The only limitation to stop the compressor is the maximum pumpdown time. **G11** should be adjusted in a way that, at all operating conditions, it allows pumpdown to compressor cut-out value **C02** plus a defined safety time, eg, 2 minutes.

2.15.4 Internal pumpdown with temperature sensor (case temperature)

It is also possible to carry out pumpdown functionality in case a temperature sensor is used for temperature control (not part of the standard delivery). Parameters **G56** and **S07** have to be set up as described in section 2.15.3 "Pumpdown with room thermostat (not available on ZXDY units)".

The control of a cold room or cooling cabinet can be realized with a temperature sensor (change parameter **G01** according to the probe location). Parameter **A19** must be set up as thermostat temperature. The

temperature setpoint is defined by parameter **G02**. Adjust the temperature range with positive differential value **G03**.




Figure 17: Pumpdown functionality with temperature sensor

If the temperature increases and reaches setpoint plus differential, the liquid line solenoid output relay will energize the coil to open the valve. The compressor will be controlled by suction pressure.

The temperature value is to be set between parameters **G04** and **G05**.

In case of fault in the thermostat probe the opening and the closing of the solenoid valve relay are timed through limp-along parameters (**G06** and **G07**).

Parameter	Factory settings	Pumpdown settings / Comments
A19	0 = Not used = nu	2 = Thermostat temperature = tnt
C01	2.7 / 0.4 bar rel	Cut-in value for pumpdown
C02	1.1 / 0.1 bar rel	Cut-out value for pumpdown, eg, 0.2 bar rel
C05	1 = Suction pressure probe = SuP	2 = Case temperature probe = CSt
G01	0 = Not used = nu	4 = Thermostat temperature = tnt
G02	+2 °C	Setpoint for temperature, eg, +2 °C for meat
G03	+1 °C	Positive differential defines upper cut-out value
G04	-10 °C	Lower setpoint limit
G05	+15 °C	Upper setpoint limit
G06	2 minutes	On time in case of probe failure
G07	1 minute	Off time in case of probe failure
G11	3 minutes	Maximum pumpdown time
G56	0 = No	1 = Yes
S07	0 = Not used = nu	7 = Liquid line solenoid = LLS

Table 27: Internal pumpdown with temperature sensor

If temperature \geq **G02** + **G03**, switch on liquid line solenoid.

If temperature \leq **G02**, switch off liquid line solenoid and the compressor will continue to operate until most of the refrigerant on the low side boils off and is pumped through the compressor into the condenser and receiver. As the suction pressure falls below the low-pressure cut-out value (**C02**), the compressor will cycle off.

The temperature value depends both on parameter **G02** and parameter **G11** (maximum pumpdown time). It means that when the liquid line solenoid is off, the compressor will stop because of suction pressure decrease within **G11** time. If the running time of the compressor exceeds **G11** value, the compressor will be forced to shut down and the controller will generate a pumpdown alarm.

2.16 Reset to factory settings – Copeland Hot Key

2.16.1 How to save factory settings or user settings

There is no way to reset the XCM25D controller to factory settings other than with additional equipment. Copeland recommends using the Copeland Hot Key (not part of the standard delivery) to save the factory settings at initial power up. The same hot key can also be used to save user settings.

Thanks to a special programming software (Copeland Wizmate) and corresponding hardware (Copeland Prog-Tool), the user can:

- pre-program hot keys
- copy hot keys
- change parameter levels
- compare parameter lists

For further information please visit our website at www.copeland.com/en-gb or contact your local Application Engineering representative at Copeland.

2.16.2 Copeland Hot Key for ZX*Y units with XCM25D controller

The Copeland Hot Key **DK00000300** can be used for uploading and downloading of parameter lists. Copeland ident number 3226456.



Figure 18: Copeland Hot Key

2.16.3 Location of the hot key plug connection on the XCM25D controller

The hot key plug connection is located on the upper left corner of the XCM25D.



Figure 19: Location of Hot Key plug connection

2.16.4 How to program a hot key from the controller (upload)

- Program the controller with the front keypad.
- When the controller is on, insert the hot key and press the UP key; the "uPL" message appears followed by a flashing "End" label.
- Press the SET key and the "End" label will stop flashing.
- Turn the controller off, remove the hot key and then turn it on again.

NOTE: The "Err" message appears in case of a failed programming operation. In this case press the UP key again to restart the upload or remove the hot key to abort the operation.

2.16.5 How to program a controller using a hot key (download)

- Turn the controller off.
- Insert a pre-programmed hot key into the 5-pin receptacle and turn the controller on.
- The parameter list of the hot key will be automatically downloaded into the controller memory. The "doL" message will blink followed by a flashing "End" label.
- After 10 seconds the controller will restart working with the new parameters.
- Remove the hot key.

NOTE: The message "Err" is displayed in case of a failed programming operation. In this case turn the controller off, then on again to restart the download or remove the hot key to abort the operation.

2.17 Troubleshooting – Alarm history

The controller records the total number of alarm activations (max 50) in the alarm menu – see **Appendix 5**.

Action	Key or display	Notes
Enter menu		Push and release the ALR key.
Waiting for action	SEC	The menu to change the section will be entered. The alarm list section is active.
Enter section list		Press SET to confirm. The following list will be available to select the proper network function.
Select active alarm code from list	 or 	Scroll the list of active alarms by alarm number (letter + number, A01-A50). Press to see the alarm name or code. Press to see the next active alarm.
Select the alarm to see the detailed rtC information		Enter the sub menu with alarm time details.
Select detailed information from active alarm list	 or 	<p><u>With the rtC activated:</u> The Hur (hour) parameter is displayed. Press to see the alarm hour. Press : Min is displayed. Press to see the alarm minute. Press : dAy is displayed. Press to see the alarm day. Press : MOn is displayed. Press to see the alarm month. Press : YEA is displayed. Press to see the alarm year.</p> <p>NOTE: The clock info indicates the START time of the alarm.</p> <p><u>Without the rtC activated:</u> The COh (hours) parameter is displayed. Press to see the compressor working hours. To exit: press or wait for 15 seconds without pressing any key.</p>
Exit menu		Press simultaneously or wait for about 10 seconds without pressing any key.

Table 28: How to check the alarm list

2.18 Compressor motor protection

The electronic controller protects the compressor motor against the following:

- overcurrent;
- phase loss;
- incorrect phase rotation;
- voltage imbalance.

If the compressor motor current exceeds a predefined (non-adjustable) current limit, the electronic controller shuts the unit down and generates an error signal. For this function two of the main phase supply lines to the compressor (compressor via the contactor) are routed through the current sensors.

2.19 System pressure protection

A high-pressure safety switch is registered by the electronic board. The sensing device is a non-adjustable, high-pressure switch that will open in the event of an abnormally high discharge pressure (above 28 bar for all unit models).

- The unit will stop then and restart automatically after a 5-minute delay and after the unit pressure has decreased to 22 bar.
- After 7 successive HP cut-outs over 1 hour, the unit will lock out. In this case a manual reset will be necessary.

2.20 Other inputs of the XCM25D controller

2.20.1 Customer-supplied control (room thermostat)

The XCM25D electronic controller uses a digital input (**DI3**) open/close signal (such as the switching action of a normal commercial thermostat) and relays a similar action as an output to the compressor contactor in the case of a thermostat-controlled (parameter **C05**) system – see wiring diagrams in **Appendices 2 & 3**. If the system is controlled by low-pressure cut-out for a multiple evaporator system and/or pumpdown system, the controller accepts signals directly from an adjustable low-pressure switch (optional).

2.20.2 Case temperature controller

An alternative method of system temperature control can be used. The electronic controller accepts an input from a common commercial thermostat (**DI3**, digital input). For details see **section 2.10.5 "Additional features for customization"**.

2.20.3 Ambient temperature sensor

An ambient temperature sensor is connected to the electronic controller. This temperature sensor has several functionalities like emergency mode control, lower fan speed limitation and crankcase heater control. The sensor is located on the backside of the compressor compartment.

2.21 Alarm output (DO5) of the XCM25D controller

The digital output **DO5** is pre-configured as an alarm contact. The relay (max. 5 A, 250 VAC) is activated in case of alarms and lockouts. Warnings will be shown only on the controller display.

3 Installation



WARNING
High pressure! Injury to skin and eyes possible! Be careful when opening connections on a pressurized item.



IMPORTANT
 The installation location must be selected in accordance with local workplace safety regulations.

Copeland ZX*Y refrigeration units are delivered with a holding charge of neutral gas.

The refrigeration unit should be located in such a place to prevent any dirt, dust, plastic bag, leaves or papers from covering the condenser and its fins.

The unit must be installed in such a way that the airflow is not restricted.

A clogged condenser will increase the condensing temperature, thus reduce the cooling capacity, and lead to a high-pressure switch tripping. Clean the condenser fins on a regular basis.

3.1 Refrigeration unit handling

3.1.1 Transport and storage



WARNING
Risk of collapse! Personal injuries! Move units only with appropriate mechanical or handling equipment according to weight. Keep in the upright position. Respect stacking loads according to **Figure 20**. Do not stack anything on top of the unit packaging. Keep the packaging dry at all times.



Respect the maximum number of identical packages which may be stacked on one another, where "n" is the limiting number:

- **Transport: n = 0**
- **Storage: n = 0**

Figure 20: Maximum stacking loads for transport and storage

3.1.2 Weights

Refrigeration units					
Medium temperature				Low temperature	
Standard	Weight (kg)	Digital	Weight (kg)	Standard	Weight (kg)
ZXMY-020E	73			ZXLY-020E	78
ZXMY-030E	80	ZXDY-030E	85	ZXLY-030E	81
ZXMY-040E	86	ZXDY-040E	106	ZXLY-040E	93
ZXMY-050E	112	ZXDY-050E	118	ZXLY-050E	110
ZXMY-060E	114	ZXDY-060E	120	ZXLY-060E	114
ZXMY-075E	116	ZXDY-075E	122	ZXLY-075E	120

Table 29: Weights

3.2 Refrigeration piping connections

3.2.1 Refrigeration piping installation



WARNING

High pressure! Risk of personal injury! The units are pressurized with dry air. Be careful when opening connections on a pressurized item.



WARNING

Low surface temperature! Danger of frostbite! The liquid line should be insulated with 19 mm insulation thickness. The temperature could be as low as -15 °C.



IMPORTANT

Tube quality! Installation contamination! All interconnecting piping should be of refrigeration grade, clean, dehydrated and must remain capped at both ends until installation. Even during installation, if the system is left for any reasonable period of time, eg, 2 hours, pipes should be re-capped to prevent moisture and contaminant from entering the system.

Connection sizes! Unsuitable refrigerant flow rate! Do not assume that the service connection sizes on the unit (at the service valves) are in fact the correct size to run the interconnecting refrigeration pipes. The service valve sizes have been selected for convenience of installation and in some cases (larger units) these may be considered too small. However, for the very short pipe run within these units these service connection sizes are adequate. All interconnecting piping should be sized to satisfy the duty required.

The pipe should be sized to ensure optimum performance and good oil return. The sizing must also take into account the full capacity range through which a particular unit will need to operate.

Unit	Suction line (ODS)	Liquid line (IDS)
ZXMY-020E & ZXMY-030E ZXDY-030E ZXLX-020E & ZXLX-030E	3/4" (19.05 mm)	1/2" (12.7 mm)
ZXMY-040E to ZXMY-075E ZXDY-040E to ZXDY-075E ZXLX-040E to ZXLX-075E	7/8" (22.23 mm)	1/2" (12.7 mm)

Table 30: Piping connection sizes

Pipe runs should be kept as short as possible, using the minimum number of directional changes. Use large radius bends and avoid trapping of oil and refrigerant. This is particularly important for the suction line. The suction line should ideally slope gently towards the unit. Recommended slope is 1/200 to 1/250. Upper and lower oil traps, double risers and reduced pipe diameters may be required for suction lines where long vertical risers cannot be avoided.

All pipes should be adequately supported to prevent sagging which can create oil traps. The recommended pipe clamp support distances are shown in **Table 31** below:

Tube size	Max distance between 2 clamp supports
1/2" (12.7 mm)	1.20 m
5/8" (16.0 mm)	1.50 m
7/8" (22.0 mm)	1.85 m
1 1/8" (28.5 mm)	2.20 m

Table 31: Maximum distances between 2 clamp supports

3.2.2 Brazing recommendations



WARNING

Air/flammable refrigerant mixture! Creation of a potentially flammable atmosphere! Fire hazard! Remove all refrigerant before opening the system. When working on a refrigerant-filled system, make sure to follow the safety and working instructions given in **Chapter 5 "Maintenance & repair"**.



WARNING

High temperature! Burning! Proceed with caution when brazing system components. Do not touch the compressor until it has cooled down. Ensure that other materials in the area of the compressor do not come into contact with it.



CAUTION

Blockage! Compressor breakdown! Maintain a flow of oxygen-free nitrogen through the system at very low pressure during brazing. Nitrogen displaces the air and prevents the formation of copper oxides in the system. If allowed to form, the copper oxide material can later be swept through the system and block screens such as those protecting capillary tubes, thermal expansion valves, and accumulator oil return holes.

Contamination or moisture! Bearing failure! Do not remove the plugs until the compressor is set into the unit. This minimises any entry of contaminants and moisture.

- Remove the discharge connection cap.
- Remove the suction connection cap.
- Open both valves mid-way. Care should be taken to avoid the holding charge releasing too quickly.
- Be sure tube fitting inner surface and tube outer surface are clean prior to assembly.
- Both tubes are extended from the refrigeration unit housing, therefore we recommend to isolate the housing by using a wet cloth on the copper tubing.
- Recommended brazing materials: a copper/phosphorous or copper/phosphorous/silver alloy rod should be used for joining copper to copper whereas to join dissimilar or ferric metals a silver alloy rod either flux coated or with a separate flux would be used.
- Use a double-tipped torch.




Figure 21: Brazing – Sectional view

3.2.3 Brazing procedure



WARNING

Air/A2L refrigerant mixture! Fire hazard! For systems using flammable A2L refrigerant, it is mandatory to flush oxygen-free nitrogen through the piping during the brazing process. Brazing must be carried out in compliance with ISO 14903.

Refer to **Figure 22** and procedure below for the brazing of the tubes:




Figure 22: Suction tube brazing areas

- Fit the copper tube into the unit tube.
- Heat area 1. As the tube approaches brazing temperature,
 - heat area 2 until braze temperature is attained. It is necessary to heat the tube evenly. Move the torch up and down and rotating around the tube.
 - Add braze material to the joint while moving the torch around the joint to flow braze material around the circumference.
- Then heat area 3. This will draw the brazing material down into the joint.

- Recommended brazing material: Silfos with minimum 5 % silver or silver braze used on other compressors.

NOTE: The time spent heating area 3 should be minimal. As with any brazed joint, overheating may be detrimental to the final result.

NOTE: Due to the different thermal properties of steel and copper, brazing procedures may have to be changed from those commonly used.

To disconnect:

- Heat joint areas 2 and 3 slowly and uniformly until solder softens and tube can be pulled out of the fitting.

To reconnect:

- See procedure above.

3.3 Electrical connection




WARNING

Conductor cables! Electrical shock hazard! Shut off power supply before undertaking any task on electrical equipment.




WARNING

Ignition source in a potentially flammable atmosphere! Fire hazard! The electrical connection of the scroll compressors is not an ignition source during normal operation but could become one if not installed properly according to installation instructions. Ensure correct mechanical and electrical installation. System capacitors may remain charged for several minutes after shutdown. Before starting to work on the electrical installation make sure sparking is not possible. Continuously check if the ambient atmosphere is non-flammable when working on the electrical installation.



IMPORTANT

It is strongly recommended to install an additional circuit breaker for the unit power supply in order to be able to switch the unit off remotely in case of failure.



IMPORTANT

The front cover of the electrical cabinet is protected by a ground connection. Open the electrical box cover carefully to avoid pulling out the ground wire.

3.3.1 Power supply connections



WARNING

Electrical pins under voltage! Electrical shock hazard! There are unused fast-on pins (C1 & DO2) on the XCM25D which could be under voltage. They are covered by insulated fast-on flags in the factory. Handle carefully when removing insulating flags during service on site.

The electrical connection of the refrigeration unit to the power supply must be made by qualified technicians in compliance with valid electrical standards, for instance DIN EN 60204-1. Additionally, the voltage drop and line temperatures must be considered for cable selection.

Copeland ZX*Y refrigeration units are designed for 380-420 V / 3 Ph / 50 Hz power supply. A voltage tolerance of $\pm 10\%$ is acceptable.

The main switch and the circuit breaker must be switched off before opening the front panel.

Before commissioning, ensure that the neutral "N" and ground protection "PE" wires are connected to the main switch. The ground connections are indicated by red circles in the following figures.




Figure 23: Ground connection on top cover, right cover and divider

All accessible metallic parts or objects within 3 metres of the refrigeration unit, eg, metal pipes, fence, ladders, railings etc... must be grounded with a dedicated grounding connection. A separate ground connection is provided on the baseplate of the unit (lower ground connection in **Figure 24** below).




Figure 24: Ground connection on right cover and baseplate




Figure 25: Ground connection on fan bracket and base plate




Figure 26: Ground connection on door




Figure 27: Ground connection on condenser




Figure 28: Ground connection in electrical cabinet

3.3.2 Maximum operating currents for cable selection

Unit model	Locked rotor	Rated current
Medium temperature standard units		
ZXMY-020E-TFM/TFD	26.0 A	5.21 A
ZXMY-030E-TFM/TFD	32.0 A	6.51 A
ZXMY-040E-TFM/TFD	50.0 A	8.81 A
ZXMY-050E-TFM/TFD	64.0 A	11.62 A
ZXMY-060E-TFM/TFD	74.0 A	13.32 A
ZXMY-075E-TFM/TFD	102.0 A	17.42 A
Medium temperature digital units		
ZXDY-030E-TFM/TFD	40.0 A	7.71 A
ZXDY-040E-TFM/TFD	48.0 A	11.52 A
ZXDY-050E-TFM/TFD	64.0 A	12.82 A
ZXDY-060E-TFM/TFD	74.0 A	13.82 A
ZXDY-075E-TFM/TFD	102.0 A	17.42 A
Low temperature standard units		
ZXLY-020E-TFD	24.0 A	6.20 A
ZXLY-030E-TFD	36.0 A	7.20 A
ZXLY-040E-TFD	46.5 A	9.20 A
ZXLY-050E-TFD	58.0 A	11.20 A
ZXLY-060E-TFD	67.0 A	13.70 A
ZXLY-075E-TFD	92.0 A	17.20 A

Table 32: Unit maximum rated currents for cable selection

3.3.3 Electrical protection standard (protection class)

- Units: IP class IPX4.
- Scroll compressors (YB*, YBD* & YF*): IP54 according to IEC 34.
- Fans: IP44 according to IEC 34.
- Solenoid valve coils: IP65 according to DIN 43650.

3.3.4 Terminal box



WARNING

Ignition source in a potentially flammable atmosphere! Fire hazard! Any work on the energized terminals in the compressor terminal box could create an ignition. Do not touch the energized terminals with a tool or cable when the compressor is energized.

Compressors operating with flammable refrigerants shall use only the qualified terminal box supplied with the compressor.



CAUTION

Mechanical stress or shock! Overheating! Terminal Fusite damage and leakage! Mechanical stress and shocks to the Fusite must be avoided as they could damage the glass and/or ceramic which could result in hermeticity failure or loss of terminal performance. Precautions are required to prevent striking or bending of pins as it might result in hermeticity failure or loss of terminal performance.

Ensure correct connection of cables to the compressor terminal Fusite to avoid local overheating of Fusite pins which might lead to refrigerant leaks.

3.3.5 Low-pressure protection



WARNING

Operation below ambient pressure! Fire hazard! During operation below ambient pressure, a flammable mixture can form inside the system. Make sure that air does not enter the system.



CAUTION

Operation outside the application envelope! Compressor breakdown! A low-pressure protection shall be fitted in the suction line to stop the unit when it operates outside the envelope limits.

Make sure that the pressure never falls below atmospheric pressure. If it does, immediately de-energize the power supply of the unit and check the cause of the low pressure before restarting the unit.

3.3.6 Crankcase heater



IMPORTANT

Oil dilution! Bearing malfunction! Turn the crankcase heater on 12 hours before starting the unit.

The initial start-up in the field is a very critical moment for any compressor because all load-bearing surfaces are new and require a short break-in period to carry high loads under adverse conditions. **The crankcase heater must be turned on a minimum of 12 hours prior to starting the unit.** This will prevent oil dilution and bearing stress on compressor initial start-up. **The crankcase heater must remain energized during compressor off cycles.**

3.3.7 Insulation material

Insulation material is commonly used in a system to insulate the suction line, suction accumulator, expansion valve bulb or discharge line thermostat. When choosing the insulation material, particular attention shall be paid to its non-electrostatic properties, as it could be a potential ignition source.

3.3.8 Vibration



WARNING

Vibrations! Creation of a flammable atmosphere! Carefully check the system for vibrations.

Vibrations during unit operation can cause cracks which could lead to refrigerant leakage. This situation must be avoided by the system manufacturer/installer. To this end, the pipework must be carefully designed when connecting the unit to a system.

3.3.9 High-potential testing



WARNING

High-potential testing in a flammable atmosphere! Fire hazard! Make sure the atmosphere is non-flammable before performing high-potential testing. **DO NOT** perform any high-potential test when the compressor is charged with flammable refrigerant.



WARNING

Conductor cables! Electrical shock hazard! Shut off power supply before high-potential testing.



CAUTION

Internal arcing! Motor destruction! Do not perform high-voltage or insulation tests if the compressor housing is under vacuum.

Copeland subjects all units to a high-voltage test after final assembly. Each unit is tested according to EN 60034-1 at a differential voltage of 1000 V plus twice the nominal voltage.

Since high-voltage tests lead to premature ageing of the winding insulation, further additional tests of that nature are not recommended. However, if they are absolutely needed, they shall not be done with the unit charged with refrigerant and they should be conducted with a lower voltage than described above. Disconnect all electronic devices, eg, motor protection module, fan speed control, etc prior to testing.

Special attention should be paid when performing a high-potential test and reading the Megohm resistance on A2L units, as such tests can induce an electrical arc and cause a fire hazard.

For the same reason, compressors removed from a system with A2L refrigerant will need to have the oil drained and a nitrogen purge introduced to flush any remaining refrigerant from the compressor prior to high-potential testing and Megohm resistance reading.

3.3.10 Circuit breaker with overcurrent protection



WARNING

Isolating switch "On"! Electrical shock hazard! Turn off the main power supply to de-energise the unit before undertaking any task on the electrical equipment.

Each unit is equipped with a circuit breaker with overcurrent protection. In case of overcurrent shut-off, reset must be done manually by a qualified technician.



Figure 29: Circuit breaker with overcurrent protection

Refrigeration units					
Medium temperature				Low temperature	
Standard	Setting	Digital	Setting	Standard	Setting
ZXMY-020E	4.1 A			ZXLY-020E	5.0 A
ZXMY-030E	5.2 A	ZXDY-030E	7.3 A	ZXLY-030E	6.0 A
ZXMY-040E	7.3 A	ZXDY-040E	10 A	ZXLY-040E	8.0 A
ZXMY-050E	10.3 A	ZXDY-050E	11.3 A	ZXLY-050E	10.0 A
ZXMY-060E	11.8 A	ZXDY-060E	12 A	ZXLY-060E	12.5 A
ZXMY-075E	15.9 A	ZXDY-075E	15.9 A	ZXLY-075E	16 A

Table 33: Main fuse settings

3.4 Pressure relief valve (PRV)

To meet the damage limitation requirements in the event of an external fire, a pressure relief valve should be fitted on the ZX*Y refrigeration unit using the dedicated 3/8" NPT connection port. Make sure to select a PRV that is qualified for this purpose and application. It is also recommended to select a valve with a thread or any other connection on the outlet so that a valve discharge pipe can easily be connected.

3.4.1 Pressure relief valve minimum requirements

Inlet connection	3/8" NPT
Outlet connection	1/2" SAE flare or bigger
Minimum flow area	31.67 mm ²
Minimum Kv value	0.68 m ³ /h
Pressure relief setpoint	1.0 x PS = 31 bar

Table 34: PRV minimum requirements

3.4.2 Pressure relief valve installation

NOTE: The PRV manufacturer's instructions must be carefully followed during the PRV installation process.

- 1) Remove the top cover to access the PRV connection port.




Figure 30: Top cover of ZX*Y refrigeration units




Figure 31: Access to PRV port

- 2) Unscrew the NPT plug. Hold the fitting while unscrewing to avoid damaging the brazing joint on the fitting.




Figure 32: PRV port without plug

- 3) Connect the discharge pipe to the PRV outlet and lead the discharge pipe to the outside of the refrigeration unit – see example in **Figure 33** below. If needed, fix the discharge pipe to avoid vibrations.

PRV discharge pipe requirements:

- Maximum length: 6 m
- Minimum internal diameter: 10 mm





Figure 33: Example of pressure relief valve and discharge pipe configuration

- 4) Carry out a leak test to ensure that there is no leakage between the brazing joint of the PRV fitting and the end of the discharge pipe.

3.5 Location & fixings



IMPORTANT

Dust and dirt contamination! Unit lifetime reduction! The unit should always be installed in a location that ensures clean airflow. External fouling of the condenser fins also leads to high condensing temperatures and will reduce the lifetime of the unit.

It is recommended to maintain a clearance of 300 mm between the wall (or the next unit) and the unit left and rear panels whereas a clearance of 500 mm must be maintained from the unit right, top and front panels seen facing the front of the unit – see **Figures 34 & 35**. Both service access and airflow have been considered in making these recommendations.

Where multiple units are to be installed in the same location, the contractor needs to consider each individual case carefully. There can be many variations of unit quantities and available space and it is not the intention of this manual to go over these. However, in general terms, air by-pass around each condenser and between the units should be avoided at all times.




Figure 34: Fixing dimensions and distances – Single-fan units




Figure 35: Fixing dimensions and distances – Dual-fan units

Ideally, the unit should be mounted level on a solid concrete slab with anti-vibration pads between unit feet and concrete. However, the ZX*Y refrigeration unit has also been designed for wall mounting on suitable brackets. In this case it is equally important that the dimensional guidelines given above are followed and that additional consideration is given for possible air recycling if units are installed one above the other. Wall mounting brackets are not part of the standard delivery.

Another factor to consider in finding a good installation site is the direction of the prevailing wind. For example, if the air leaving the condenser faces the prevailing wind, the airflow through the condenser can be impeded, causing high condensing temperatures and ultimately resulting in reducing the unit lifetime. A baffle is a remedy for this situation.

4 Start-up & operation



WARNING

Diesel effect! System explosion! The mixture of air and oil at high temperature can lead to an explosion. Avoid operating with air.



WARNING

Air/flammable refrigerant mixture! Creation of a flammable atmosphere! Make sure the atmosphere is non-flammable before starting the system. Ensure that the system contains only refrigerant and there is no flammable gas in the ambient.
Ensure proper ventilation according to the room volume and to the refrigerant charge.

4.1 Strength-pressure test



WARNING

High pressure! Personal injuries! Consider personal safety requirements and refer to test pressures prior to test.



IMPORTANT

System contamination! Bearing malfunction! Use only dry nitrogen for pressure testing. DO NOT USE other industrial gases.

NOTE: For more information please refer to the compressor application guidelines.

4.2 System tightness test



WARNING

High pressure! Personal injuries! Consider personal safety requirements and refer to test pressures prior to test.



IMPORTANT

System contamination! Bearing malfunction! Use only dry inert gases (for example nitrogen) for leak testing. DO NOT USE other industrial gases.

Any later modification to compressor connections can have an impact on the compressor tightness. Always leak-pressure test the compressor after opening or modifying the connections.

4.3 Evacuation



CAUTION

Inadequate refrigerant charge! Compressor damage! Never energize the unit/controller without minimum refrigerant system charge. There is a risk of malfunction of the controller in deep vacuum operation which can cause compressor damage.



IMPORTANT

The evacuation procedure is based upon achieving an actual system vacuum standard and is NOT TIME DEPENDENT! The installation has to be evacuated with a vacuum pump before commissioning. Proper evacuation reduces residual moisture to 50 ppm. The installation of adequately sized access valves at the furthest point from the compressor in the suction and liquid lines is advisable. The system must be evacuated down to less than 3 mbar. If required break the vacuum with dry nitrogen. Pressure must be measured using a vacuum pressure gauge on the access valves and not on the vacuum pump. This serves to avoid incorrect measurements resulting from the pressure gradient along the connecting lines to the pump.

Before the installation is put into commission, it has to be evacuated with a vacuum pump. The vacuum pump and all tools have to be approved for A2L refrigerant/air mixture. The installation should be evacuated down to an absolute pressure of 3 mbar. Proper evacuation reduces residual moisture to 50 ppm. During the initial procedure, suction and discharge shut-off valves on the compressor remain closed. The installation of adequately sized access valves at the furthest point from the compressor on the suction and liquid lines is advisable. The pressure must be measured using a vacuum pressure gauge on the access valves and not on the vacuum pump; this serves to avoid incorrect measurements resulting from the pressure gradient along the connecting lines to the pump.

The highest demands are placed on the leak-proof design of the installation and on the leak testing methods – please refer to EN 378.

4.4 Charging procedure

4.4.1 Refrigerant charging procedure



WARNING

Air/A2L refrigerant mixture in a potentially flammable atmosphere! Fire hazard! Only use filling equipment designed and approved for use and operation with A2L refrigerant. Make sure all connections are tight to avoid leakage. Make sure to fill with pure A2L refrigerant.

Whenever starting up a system charged with A2L refrigerant, eg, after filling, repair, or maintenance, make sure not to start and operate accidentally in a flammable atmosphere.



CAUTION

Service valve closed! Compressor damage! Do not charge the unit with vapour (gas). The suction service valve must never be fully closed when the compressor is running. This would cause damage to the compressor in the same manner as explained above. This valve is provided for ease of connection and for the fitting of service gauges without removing the unit panel.



IMPORTANT

Inadequate charge! Overheating! The scroll compressor design requires the system to be charged as quickly as possible with liquid refrigerant into the liquid line. This will avoid running the compressor under conditions whereby insufficient suction gas is available to cool not only the motor but also the scrolls. Temperature builds up very quickly in the scrolls if this is not done.



IMPORTANT

Refrigerant leakage! Contamination of surroundings! In case of leakage the surrounding area can be contaminated with a mixture of oil and refrigerant. Periodically check the system for leakage.

Before charging or re-charging, the system must be leak- and pressure-tested with appropriate purging gas.

Ensure that the refrigerant system is grounded prior to charging with refrigerant.

Pre-charging must be carried out with liquid refrigerant through the service valve on the liquid line. It is advisable to pre-fill the suction side with a partial charge to avoid vacuum operation. Further charging can be done by carefully filling refrigerant through the suction line while simultaneously checking the sight glass.

The system charge varies from system to system and therefore must always be adapted to the required application. The refrigerant charge of the unit itself can be calculated approximately based on the following:

- One-fan units: $0.1 \text{ L} + 3.28 \text{ L} + 0.1 \text{ L} = 3.48 \text{ L}$ (condenser 10 % + receiver 80 % + liquid line 100 %)
- Two-fan units: $0.29 \text{ L} + 4.72 \text{ L} + 0.2 \text{ L} = 5.21 \text{ L}$ (condenser 10 % + receiver 80 % + liquid line 100 %)

The percentage values refer to the part of the refrigerant that is liquid in the particular component.

Extreme care shall be taken not to overfill the system with refrigerant. The system manufacturer/installer must respect the charge limitations according to valid standards, such as but not limited to EN 378.




Figure 36: Service valves for refrigerant charging

NOTE: In order to meet the requirements of the Ecodesign Directive 2009/125/EC with regard to efficient system operation, ensure the refrigerant charge is sufficient.

4.4.2 Oil charging procedure

Copeland ZX*Y refrigeration units are pre-charged with oil. After commissioning, the oil level should be checked and topped up if necessary.

As mentioned in **section 2.6.1 "Qualified refrigerants and oils"**, Copeland recommends charging with one of the following oil types:

- Emkarate RL 32 3MAF
- Mobil EAL Arctic 22 CC

Charging is done through the Schraeder valve located on the suction line.

4.4.3 Oil separator

Some unit models are equipped with an oil separator – see **section 2.7 "BOM variations"**. The separator is pre-charged with 0.5 litre of oil.

4.5 Rotation direction of scroll compressors

Scroll compressors, like several other types of compressors, will only compress in one rotational direction. Direction of rotation is not an issue with single-phase compressors since they will always start and run in the proper direction. Three-phase compressors are protected against wrong rotation field by the unit controller.

4.6 Maximum compressor cycle


Maximum permitted starts per hour: 10. The factory setting of the XCM25D system controller already takes into account the maximum permitted starts and stops of the compressor and also controls running time and minimal downtime. It is recommended to change these settings only in exceptional cases.

4.7 Checks before starting & during operation



WARNING

Air/A2L refrigerant mixture in a potentially flammable atmosphere! Fire hazard! Whenever starting up a system charged with A2L refrigerant, eg, after filling, repair, or maintenance, make sure not to start and operate accidentally in a flammable atmosphere.



IMPORTANT

Liquid valves not fully opened! Liquid trap! Both valves should be fully opened on the liquid line in order to prevent liquid trapping.

Before a system runs for the first time:

- Check that the valves on the liquid line are fully opened.
- Set the essential parameters of the electronic controller in the programming level 1 (refrigerant type, compressor cut-out/cut-in settings (ZXDY only), fan setpoint....) according to the required application.
- Carry out visual inspection.
- Perform control tests to ensure all controls operate correctly, including any manual backup system (if applied).
- Check also the following:
 - ✓ Documentation for the system and its marking, especially pressure equipment.
 - ✓ Installation of safety devices.
 - ✓ Compressor oil level.
 - ✓ Pressure test records.
 - ✓ All valves open/closed as required for operation.

After start-up and when operation conditions have stabilised:

- It is recommended to check the oil level in the compressors and to add oil if necessary to ensure a sufficient oil level.
- The following should also be checked:
 - ✓ Fan rotation.
 - ✓ Refrigerant charge.
 - ✓ Expansion valve superheat.

4.8 Pressure fluctuations in case of digital unit

Digital scroll compressors are capable of capacity modulation. A normally closed (de-energized) solenoid valve is a key component for achieving modulation. When the solenoid valve is energized, the two scroll elements move apart axially into the unloaded state. In this state, the compressor motor continues running, but there is no compression. Within scroll modulation the suction and the discharge pressure could fluctuate. During the unloaded state, the discharge pressure will decrease and the suction pressure will increase. This normal pressure fluctuation has no observable effect on the reliability of the compressor or system components. However, the installation and setting of pressure controls should take this into account.

4.9 Pumpdown cycle



WARNING

Vacuum operation! Creation of a flammable mixture! Fire hazard! During operation in vacuum a flammable mixture can form inside the system. Extreme attention shall be paid to system tightness. Prevent ambient air from entering the system.

The system pressure shall not be allowed to go down below the pressure values shown in **section 2.10.4 "Main control & safety features"**. If this happens, immediately stop the unit and/or de-energize the power supply of the unit.

Please also refer to the application envelopes which can be found in Select software, available at www.copeland.com/en-gb.

5 Maintenance & repair

5.1 General considerations



WARNING

Conductor cables! Electrical shock hazard! Follow the lockout/tag out procedure and the national regulations before undertaking any maintenance or service work on the system.

Screwed electrical connections must be used in all applications. Refer to original equipment wiring diagrams. Electrical connections must be made by qualified electrical personnel.



WARNING

Ignition source in a potentially flammable atmosphere! Fire hazard! When opening the system, the atmosphere could be flammable. All electrical components that are a source of ignition must always be switched off during service and maintenance. Ensure that the surface temperatures of the components never exceed the limits set by the applicable safety standard, eg, EN 378-2.

Air/flammable refrigerant mixture! Fire hazard! Remove all refrigerant before opening the system. Make sure to remove refrigerant completely from all components such as heat exchangers, refrigerant accumulators, etc. Flush the system and the components with inert gas before undertaking any work and before brazing.



WARNING

Open flame in a potentially flammable atmosphere! Fire hazard! The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of a potentially toxic or flammable atmosphere. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants.

Personnel performing work on a refrigeration system that involves exposing the pipework shall avoid using any ignition source in a way that could lead to a fire hazard. All sources of ignition shall be kept sufficiently far from the site of installation, repair, removal or disposal during the entire time when refrigerant could be released into the surrounding space.

Open flames and smoking are strictly forbidden at all times.

In case of failure, switch the unit off remotely via the additional circuit breaker if available.

A risk analysis to evaluate all possible risks shall be carried out by the service technician before any repair work.

5.2 Qualification of workers



CAUTION

Non-qualified personnel! Improper maintenance! Only qualified and trained personnel can service or undertake work on units using flammable refrigerant.

Personnel working on the maintenance, repair and decommissioning of the system shall be adequately trained. Any work procedure affecting safety shall only be executed by qualified and trained personnel in compliance with national or other equivalent certification systems. Examples of such work procedures are breaking into the refrigerating circuit, opening sealed components, opening ventilated enclosures, etc...

5.3 Preparation and work procedure

A work procedure shall be provided in the preparation stage. All personnel working at the site, whether maintenance or other, shall be instructed on the nature of the work being carried out.

If any work is to be conducted on the refrigeration systems or any associated parts, appropriate fire extinguishing equipment shall be provided. Dry powder or CO₂ fire extinguishers are considered appropriate. Confirm that appropriate fire extinguishing equipment is available near the work area.

Prior to starting to work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized.

Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.

Avoid working on systems filled with flammable refrigerant in a confined space.

5.4 Disassembling system components

When disassembling system components the recommendations below shall be followed:

- Recover refrigerant and evacuate system using an A2L-dedicated recovery unit and vacuum pump. All the refrigerant shall be recovered to avoid significant release. Ensure that the outlet of the vacuum pump is not close to any potential ignition source and that ventilation is available.
- Flush system with inert gas (dry nitrogen). Compressed air or oxygen shall not be used for purging refrigerant systems.
- Disassemble components with a cutting tool.

5.5 Replacing a compressor



WARNING

Air/A2L refrigerant mixture! Fire hazard! Use suitable recovery unit and recycling bottles also for oil disposal as A2L refrigerant may still be solved in the oil.

For systems using flammable A2L refrigerant, it is mandatory to flush oxygen-free nitrogen through the piping during the brazing process.



CAUTION

Inadequate lubrication! Bearing destruction! Exchange the accumulator after replacing a compressor with a burned-out motor. The accumulator oil return orifice or screen may be plugged with debris or may become plugged. This will result in starvation of oil to the new compressor and a second failure.

Remove refrigerant and oil completely from the replaced compressor.

When replacing an A2L-refrigerant compressor, the oil has to be drained out of the compressor and the compressor should be flushed with dry nitrogen. DO NOT close the stubs with plugs.

In the case of a motor burnout, the majority of contaminated oil will be removed with the compressor. The rest of the oil is cleaned through the use of suction and liquid line filter driers. A 100 % activated alumina suction line filter drier is recommended but must be removed after 72 hours. **It is highly recommended to replace the suction accumulator, if the system contains one.** This is because the accumulator oil return orifice or screen may be plugged with debris or may become plugged shortly after a compressor failure. This will result in starvation of oil to the replacement compressor and a second failure. When a compressor is exchanged in the field, it is possible that a major portion of the oil may still be in the system. While this may not affect the reliability of the replacement compressor, the extra oil will add to rotor drag and increase power usage.

- De-energize the refrigeration unit before any intervention.
- Close valves to isolate the unit from the system.
- Recover the refrigerant from the unit.
- Drain, recover and dispose of compressor oil as appropriate.
- Make sure that the compressor is not under pressure.
- Release the compressor mounting parts then lift the compressor and replace it with the new one.




Figure 37: Tube connecting areas

To disconnect:

- Using a pipe cutting tool, cut off the suction and discharge lines in such a manner that the new compressor can easily be re-connected into the system.
- Heat joint areas 2 and 3 slowly and uniformly until the braze material softens and the tube end can be pulled out from the fitting.

To reconnect:

- See section 3.2.3 "Brazing procedure".

- Recommended brazing material: Silfos with minimum 5 % silver or silver braze used on other compressors.

NOTE: Due to the different thermal properties of steel and copper, brazing procedures may have to be changed from those commonly used.

NOTE: For more detailed instructions, please refer to the compressor application guidelines.

5.6 Exchanging the refrigerant



WARNING

Air/A2L mixture in a potentially flammable atmosphere! Fire hazard! In any case avoid air/A2L mixture in the refrigeration system. Make sure that the system is filled with pure A2L refrigerant. In the event that the refrigerant needs replacing, the charge should be recovered using A2L-qualified refrigerant recovery unit and recycling bottles.

For qualified refrigerants and oils, see **section 2.6.1**.

5.7 Replacing the crankcase heater



WARNING

Ignition source in a potentially flammable atmosphere! Fire hazard! The crankcase heater is not an ignition source during normal operation in an A2L system but could become one if not installed properly according to installation instructions. Ensure correct electrical and mechanical installation.



CAUTION

Overheating and burnout! Compressor damage! Never apply power to the crankcase heater in free air, before the crankcase heater is installed on the compressor or when it is not in complete contact with the compressor shell.

NOTE: Please refer to the Copeland spare parts catalogue available at www.copeland.com/en-gb/tools-resources to select the correct crankcase heater model.

Caution: Crankcase heaters must be properly grounded!

For the replacement of the crankcase heater, the manufacturer/installer shall follow the recommendations mentioned below.

Assembly instructions

- Choose the appropriate model according to compressor size and required wattage.
- Check the compressor application guidelines for crankcase heater connection and operation.
- Position the crankcase heater between the lower cover and the lower bearing weld projection (**Fig. 38**).
- Fit the heater horizontally around the crankcase, ensuring that it is in close contact with the compressor housing along the entire length.
- Avoid having the heating portion of the heater in contact with any weld projection (**Fig. 39 & 40**).
- Avoid having the assembly heater inclined (**Fig. 41**).
- Close the lock and tighten the screw, torque: 2-3 Nm.
- The excess clamp bracket may be trimmed. Sharp edges must not come into contact with wires.
- The presence of the heater shall be made evident by the posting of caution signs or markings at appropriate locations.



Figure 38



Figure 39



Figure 40



Figure 41

Electrical connection

- Connect the crankcase heater according to the compressor application guidelines.
- The crankcase heater must be connected only to its rated voltage.
- The metal braid of the heater must be connected to a suitable earthing terminal.
- Check the resistance according to the technical data.
- Perform an insulation test before start-up.
- Electrical security and safety measures are to be provided on site.

5.8 Electrical terminations



WARNING

Isolating switch "On"! Electrical shock hazard! Turn off the main power supply to de-energise the unit before undertaking any task on the electrical equipment.

All refrigeration units will generate some degree of vibration. Copeland ZX*Y units are no exception. However, the vibration level from the compliant scroll technology is less severe than in units using reciprocating compressor technology. Thanks to this reduced vibration, these units can be mounted on simple, less expensive rubber mounting pads.

Nevertheless, over time, due to the slight vibrations and to temperature fluctuations within the unit housing, electrical terminations might become loose. The components most likely to be affected are the main terminal strip and the compressor contactor. It is suggested to check all the electrical terminations for tightness and to carry out a visual inspection of both the low voltage crimped terminals and the rubber gasket around the cabinet at least once every 6 months.




Figure 42: Visual inspection of the rubber gasket

5.9 Condenser fins



CAUTION

Acid cleaning! Corrosion of condenser fins! Do not use acidic solutions to clean the coil. After cleaning, the fins should be brushed lightly with a proper fin comb.

Condenser fins become dirty over time as ambient air is induced to the condenser. Dirty coil surfaces result in high condensing temperatures and poor unit performance. Regular cleaning is recommended, the frequency of doing so being dependent on the installation and the surrounding environment. As a general guide it is advisable to do this at least once every two months.

As a general rule and for a clean environment Copeland recommends that the fins be cleaned with liquid detergent diluted with clean water. The ZX*Y unit has a well-designed chassis with levels sloping towards a large drainage hole and provided the unit is installed level, any cleaning solution should be able to drain away. A light brush downwards (in the direction of the fins) should be done before washing to remove heavy deposits.

NOTE: In order to meet the requirements of the Ecodesign Directive 2009/125/EC with regard to efficient system operation, ensure the heat exchangers remain clean at all times.

5.10 Routine leak testing

All joints inside the system should be leak-tested as part of a regular maintenance schedule. The checking frequency is described in standard EN 378-4, Annex D. Copeland recommends checking the system tightness at least every 6 months.

NOTE: In order to meet the requirements of the Ecodesign Directive 2009/125/EC with regard to efficient system operation, ensure the refrigerant and oil charges are sufficient.

5.11 Condenser fans & motors

A yearly inspection of these items is recommended. Fastenings can become loose, bearings may wear and fans may require cleaning of solid deposits that can cause rotational imbalance.

Motors come with lifelong lubrication bearings that do not require lubricating on a routine basis, but just need to be checked for wear.

6 Certification & approval

- Copeland ZX*Y refrigeration units comply with the Low Voltage Directive LVD 2014/35/EU. The compliance is verified through harmonized standards:
 - EN 60335-1: Household and similar electrical appliances – Safety, General Requirements.
 - EN 60335-2-40: Household and similar electrical appliances – Safety, Particular requirements for electrical heat pumps, air-conditioners and dehumidifiers.
 - EN 60335-2-89: Household and similar electrical appliances – Safety, Particular requirements for commercial refrigerating appliances with an incorporated or remote refrigerant condensing unit or compressor.
- Copeland ZX*Y refrigeration units comply with the Electromagnetic Compatibility Directive EMC 2014/30/EU. The compliance is verified through harmonized standards:
 - EN 55014-1: Electromagnetic compatibility – Requirements for household appliances, electric tools and similar apparatus, Emission.
 - EN 61000-3-2: Electromagnetic compatibility (EMC) Part 3-2: Limits – Limits for harmonic current emissions (equipment input current ≤ 16 A per phase).
 - EN 61000-3-3: Electromagnetic compatibility (EMC) Part 3-3: Limits – Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, for equipment with rated current ≤ 16 A per phase and not subject to conditional connection.
 - EN 61000-6-2: Electromagnetic compatibility (EMC) Part 6-2: Generic standards – Immunity standard for industrial environments.
 - EN 61000-6-3: Electromagnetic compatibility (EMC) Part 6-3: Generic standards – Emission standard for residential, commercial and light-industrial environments.
- The Copeland ZX*Y refrigeration units and their piping comply with the Pressure Equipment Directive PED 2014/68/EU. Applied harmonized standards:
 - EN 378-2: Refrigerating systems and heat pumps – Safety and environmental requirements Part 2: Design, construction, testing, marking and documentation.
- The Copeland ZX*Y refrigeration units and their associated spare parts and accessories comply with the Directive RoHS 2011/65/EU, (EU) 2015/863 on the Restriction of the use of certain Hazardous Substances in electrical and electronic equipment (recast).
- Conformity Declarations for components are available as far as required.
- The Manufacturer's Declaration of Incorporation has to be respected when incorporating these products into a machine.

7 Dismantling & disposal



Removing oil and refrigerant:

- **Do not disperse in the environment.**
- **Use the correct equipment and method of removal.**
- **Dispose of oil and refrigerant in accordance with national legislation and regulations.**

Dispose of compressor and/or unit in accordance with national legislation and regulations.

Appendix 1: Overview of the ZX*Y unit components

Components	Medium temperature		Low temperature
	Standard ZXMY	Digital ZXDY	Standard ZXLY
Compressor M1	✓	✓	✓
Fan M2.1	✓	✓	✓
Fan M2.2	ZXMY-050E – ZXMY-075E	ZXDY-050E – ZXDY-075E	ZXLY-050E – ZXLY-075E
Y1 Stepper valve EVI	Not used	Not used	Not used
Y1 Stepper valve liquid	Not used	Not used	Not used
Y2 DGS solenoid valve	-	✓	-
E1 Crankcase heater	✓	✓	✓
S1 High-pressure switch	✓	✓	✓
S2 Low-pressure switch	-	-	-
S3 Room thermostat (optional)	-	-	-
B1 Pressure transducer suction	✓	✓	✓
B2 Pressure transducer discharge	✓	✓	✓
B3 DLT NTC discharge	✓	✓	✓
B4 EVI vapour in sensor NTC	Not used	Not used	Not used
B5 EVI vapour out sensor NTC	Not used	Not used	Not used
B6 Ambient temperature sensor NTC	✓	✓	✓
B7 Temperature sensor (optional)	-	-	-

Table 35: Overview of the ZX*Y unit components

Appendix 2: Wiring diagram – ZXMY & ZXLY units (380-420 V / 3 Ph / 50 Hz)




Figure 43: Wiring diagram – ZXMY & ZXLY units

Appendix 3: Wiring diagram – ZXDY units (380-420 V / 3 Ph / 50 Hz)




Figure 44: Wiring diagram – ZXDY units

Appendix 4: Parameters level 1

Legend

L1 = Parameter in level 1 (without password)

L2 = Parameter in level 2 (with password = 3 2 1)

N.V. = Parameter not accessible

NOTE: When changing parameters C01, C02 and C05 a reset of the controller (interruption of power supply) is required.

Parameter	Description	Range	ZXMY	ZXDY	ZXLY
C01	Compressor cut-in pressure setpoint	CoU to US; C02 to C04	L1	L2	L1
C02	Compressor cut-out pressure setpoint	LS to Cin; C03 to C01	L1	L2	L1
C07	Refrigerant selection for regulation	R404A (0-404), R507A (1-507), R134a (2-134), R22 (3-R22), R407C (4-07C), R407A (5-07A), R407F (6-07F), R448A (7-48A), R449A (8-49A), R454C (10-54C), R455A (11-55A), R454A (12-54A), R1234yf (13-123)	L1	L1	L1
C16	Digital compressor setpoint	LS to US; C03 to C04	N.V.	L1	N.V.
C17	Proportional band for compressor regulation	0.1 to 9.9 bar; 0.1 to 99.9 PSI; 1 to 999 KPA; 0.1 to 25.5 °C	N.V.	L1	N.V.
C21	Cycle time for digital compressor	10 to 40 sec	N.V.	L1	N.V.
C24	Minimum capacity for digital compressor	0 to PMA; 0 to C25	N.V.	L1	N.V.
C25	Maximum capacity for digital compressor	PMi to 100; C24 to 100	N.V.	L1	N.V.
D29	Low-pressure alarm value	0 to 15 bar	L1	L1	L1
E39	Condenser temperature setpoint when fan setpoint modulation is disabled	-40 to 110 °C	L1	L1	L1
E46	Regulation band of variable fan	0.1 to 25.5 °C	L1	L1	L1
N01	Current minute	0 to 59	L1	L1	L1
N02	Current hour	0 to 23	L1	L1	L1
N03	Date of month	1 to 31	L1	L1	L1
N04	Month	1 to 12	L1	L1	L1
N05	Year	0 to 99	L1	L1	L1
T18	Access to Pr2 level	(0÷999)	L1	L1	L1

Table 36: Parameters level 1

Appendix 5: Alarm menu

Code	Description	Cause	Action	Reset
E01	AI1 error (Probe 1 / Suction pressure transducer failure alarm)	Probe failure or out of range	Only in digital units – Compressor activated according to C23; compressor on & off times set according to D02 & D03	Automatically as soon as the probe restarts working.
E02	AI2 error (Probe 2 / Discharge pressure transducer failure alarm)	Probe failure or out of range	The fan speed control is disabled	Automatically as soon as the probe restarts working.
E03	AI3 error (Probe 3 / Discharge line temperature sensor failure alarm)	Probe failure or out of range	The discharge temperature control is disabled	Automatically as soon as the probe restarts working.
E04	AI4 error (Probe 4 / Temperature sensor failure alarm)	Probe failure or out of range		Automatically as soon as the probe restarts working.
E05	AI5 error (Probe 5 / Temperature sensor failure alarm)	Probe failure or out of range		Automatically as soon as the probe restarts working.
E06	AI6 error (Probe 6 / Ambient temperature sensor failure alarm)	Probe failure or out of range	The functions related to probe 6 (ambient temperature sensor) are disabled	Automatically as soon as the probe restarts working.
E07	AI7 error	Probe failure or out of range		Automatically as soon as the probe restarts working.
E08	Battery error			
E09	Current sensor 1 error	Probe out of range	The functions related to the current sensor are disabled	Automatically as soon as the probe restarts working.
E10	Current sensor 2 error	Probe out of range	The functions related to the current sensor are disabled	Automatically as soon as the probe restarts working.
E11	Voltage sensor 1 error	Probe out of range	The functions related to the voltage sensor are disabled	Automatically as soon as the probe restarts working.
E12	Voltage sensor 2 error	Probe out of range	The functions related to the voltage sensor are disabled	Automatically as soon as the probe restarts working.
E13	Voltage sensor 3 error	Probe out of range	The functions related to the voltage sensor are disabled	Automatically as soon as the probe restarts working.
E14-E19	<i>Reserved</i>			
E20	Lost phase error	Power supply phase loss (3-phase units)	The compressor will trip	Automatically: lost phase recovered and H08 delay elapsed. If all three phases are present but the controller still shows the error message, set parameters H06 and H25 to "No".
L20	Lost phase lockout	Power supply phase loss happened H12 times within one hour (3-phase units)	The compressor will lock out	Hold "start" button for 5 sec or manual power off and on. If all three phases are present but the controller still shows the error message, set parameters H06 and H25 to "No".

Code	Description	Cause	Action	Reset
L21	Phase sequence lockout	Incorrect phase sequence (3-phase units)	The compressor will lock out, rotation field has to be changed	Manual power off, invert 2 phases and power on. If the phase sequence is correct but the controller still shows the error message, set parameter H25 to "No".
E22	Phase imbalance	One phase voltage lower than H18 % of 3 phases average voltage (3-phase units)	The compressor is activated according to H19	Automatically: voltage recovered and H16 delay elapsed. If all three phases are present but the controller still shows the error message, set parameter H06 to "No".
E23	Overcurrent	Electrical current larger than H09 setting	The compressor will trip	Automatically: H08 delay elapsed. If the current is within the limits but the controller still shows the error message, set parameter H06 to "No".
L23	Overcurrent lockout	Overcurrent happened H11 times within one hour	The compressor will lock out (if H11 = 0, no compressor lockout)	Hold "start" button for 5 sec or manual power off and on (if H11 = 0, compressor automatically starts after H08 delay elapsed). If the current is within the limits but the controller still shows the error message, set parameter H06 to "No".
E26	Undervoltage alarm	Voltage lower than H13 setting for H15 seconds	The compressor will trip	Automatically: voltage is back within acceptable range and H16 delay elapsed. If the voltage corresponds to the required voltage but the controller still shows the error message, set parameter H06 to "No".
L26	Undervoltage lockout	Undervoltage happened H17 times within one hour	The compressor will lock out (if H17 = 0, no compressor lockout)	Hold "start" button for 5 sec or manual power off and on (if H17 = 0, compressor automatically starts when voltage is back within acceptable range and H16 delay elapsed). If the voltage corresponds to the required voltage but the controller still shows the error message, set parameter H06 to "No".
E27	Overvoltage alarm	Voltage higher than H14 setting for H15 seconds	The compressor will trip	Automatically: voltage is back within acceptable range and H16 delay elapsed. If the voltage corresponds to the required voltage but the controller still shows the error message, set parameter H06 to "No".
L27	Overvoltage lockout	Overvoltage happened H17 times within one hour	The compressor will lock out (if H17 = 0, no compressor lockout)	Hold "start" button for 5 sec or manual power off and on (if H17 = 0, compressor automatically starts when voltage is back within acceptable range and H16 delay elapsed). If the voltage corresponds to the required voltage but the controller still shows the error message, set parameter H06 to "No".

Code	Description	Cause	Action	Reset
E28	Compressor built-in thermal protector trip	High motor temperature	Warning signal only	Automatically: as soon as electrical current is detected. Check the voltage coming to the compressor.
E30	Main power lost	Controller power supply lost		
E40	High-pressure switch alarm	High-pressure switch open	The compressor will trip	Automatically: high-pressure switch closed and D14 delay elapsed. If the high pressure is below the limit but the alarm is still on, check fuse F3.
L40	High-pressure switch lockout	High-pressure switch open error happened D15 times within one hour	The compressor will lock out (if D15 = 0, no compressor lockout)	Hold "start" button for 5 sec or manual power off and on (if D15 = 0, compressor automatically starts when high-pressure switch is closed and D14 delay elapsed). If the high pressure is below the limit but the alarm is still on, check fuse F3.
E41	Low-pressure switch alarm	Low-pressure switch open	The compressor will trip	Automatically: low-pressure switch closed and D28 delay elapsed.
E43	Low pressure alarm	The pressure is below D29	Warning signal only	To deactivate the alarm function set parameter D13 to "No".
E44	Discharge line temperature alarm	Discharge line temperature higher than D22 for D24 seconds	The compressor will trip	Automatically: discharge line temperature lower than D23 setting and D25 delay elapsed.
L44	Discharge line temperature lockout	Discharge line temperature overheat happened D26 times within one hour	The compressor will lock out (if D26 = 0, no compressor lockout)	Hold "start" button for 5 sec or manual power off and on (if D26 = 0, compressor automatically starts when discharge line temperature is lower than D23 setting and D25 delay elapsed).
E45	<i>High condenser pressure alarm</i>	<i>Not used</i>		
E46	High condenser temperature alarm	Condenser temperature higher than E58 for E59 minutes	The compressor is activated according to E60	Automatically: as soon as condenser temperature is lower than E61.
E47	<i>EXV full open in EVI</i>	<i>Not used</i>		
E48	<i>Refrigerant shortage error in EVI</i>	<i>Not used</i>		
E49	<i>Pumpdown alarm</i>	<i>Not used</i>		
E50	High side floodback alarm	The differential temperature between discharge and mid-coil is lower than H21 for accumulated H22 minutes in H23 minutes	Warning signal only	Automatically: as soon as differential temperature between discharge and mid-coil is higher than H21 for H24 minutes.

Code	Description	Cause	Action	Reset
E60	Max pressure alarm of superheating	Not used		
E61	Min pressure alarm of superheating	Not used		
E62	High superheating alarm	Not used		
E63	Low superheating alarm	Not used		
E64	High room temperature alarm	Not used		
E65	Low room temperature alarm	Not used		
E66	Open door alarm	If the door is open longer than G53	Warning signal only if G09 = "no"; Alarm and compressor trip if G09 = "yes".	Manual or automatic – see Action.
E67-E79	Reserved			
E80	rtC warning, date error	HW problem in the board	Replace the controller	
E81	rtC warning, communication error	HW problem in the board	Replace the controller	
E82	Probe configuration error			
E83	DI configuration error			
E84	Compressor configuration error			
E85	Injection probe configuration error	Injection EXV output mode is selected, but no relevant sensors	Injection EXV will not work	Automatically: as soon as the injection EXV is properly configured.
E86	EEPROM R/W error (manual)	HW problem in the board	Replace the controller	
E87-E99	Reserved			

Table 37: Alarm code overview

Appendix 6: Additional features for customization

Required setting for proper functionality

Setting needs to be adjusted according to application

Room thermostat or pressure switch (not available on ZXDY units) System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
C05	Compressor regulation probe selection	SuP = Suction pressure probe	dIS = Suction pressure switch / Room thermostat
R07	Digital input 3 configuration	nu = Not used	SuS = Suction pressure switch / Room thermostat

Temperature sensor in case temperature System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
A19	Probe 7 configuration	nu = Not used	tnt = Thermostat temperature
C05	Compressor regulation probe selection	SuP = Suction pressure probe	CSt = Case temperature
G01	Case temperature probe selection	nu = Not used	tnt = Thermostat temperature
G02	Cut-out temperature	+2 °C	Adjust to application requirements
G03	Positive differential defines upper cut-in temperature	1 K	Adjust to application requirements

Pumpdown with room thermostat (not available on ZXDY units) System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
C05	Compressor regulation probe selection	SuP = Suction pressure probe	dIS = Suction pressure switch / Room thermostat
G56	Use of the liquid line solenoid	No	Yes
R07	Digital input 3 configuration	nu = Not used	SuS = Suction pressure switch / Room thermostat
R08	Digital input 3 polarity	CL = Closed	CL = Closed
S07	Relay output 4	nu = Not used	LLS = Liquid line solenoid
C01	Compressor cut-in pressure setpoint	2.7/0.4 bar rel	Adjust to application requirements
C02	Compressor cut-out pressure setpoint	1.1/0.1 bar rel	Adjust to application requirements

Pumpdown with temperature sensor in case temperature (not available on ZXDY units) System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
A19	Probe 7 configuration	nu = Not used	tnt = Thermostat temperature
C05	Compressor regulation probe selection	SuP = Suction pressure probe	CSt = Case temperature
G01	Case temperature probe selection	nu = Not used	tnt = Thermostat temperature
G56	Use the liquid line solenoid	No	Yes
S07	Relay output 4	nu = Not used	LLS = Liquid line solenoid
C01	Compressor cut-in pressure setpoint	2.7/0.4 bar rel	Adjust to application requirements
C02	Compressor cut-out pressure setpoint	1.1/0.1 bar rel	Adjust to application requirements
G02	Cut-out temperature	+2 °C	Adjust to application requirements
G03	Positive differential defines upper cut-in temperature	1 K	Adjust to application requirements

Defrost with time intervals System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
A19	Probe 7 configuration	nu = Not used	Ept = Evaporator temperature
G12	Defrost probe selection	nu = Not used	Ept = Evaporator temperature
G23	Defrost interval mode	nu = Not used	In = By time (G18)
S05	Relay output 2	nu = Not used	dEF = Defrost
G18	Interval between defrost cycles	4 min	Adjust to application requirements
G19	Maximum duration of defrost	20 min	Adjust to application requirements
G21	Defrost termination temperature	10	Adjust to application requirements
G26	Drip time	1 min	Adjust to application requirements

Defrost with Real Time Clock System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
A19	Probe 7 configuration	nu = Not used	Ept = Evaporator temperature
G12	Defrost probe selection	nu = Not used	Ept = Evaporator temperature
G23	Defrost interval mode	nu = Not used	rtC = Real time clock
S05	Relay output 2	nu = Not used	dEF = Defrost
G18	Interval between defrost cycles	4 min	Adjust to application requirements
G19	Maximum duration of defrost	20 min	Adjust to application requirements
G21	Defrost termination temperature	10 °C	Adjust to application requirements
G26	Drip time	1 min	Adjust to application requirements
G28-41	See Technical Information TI_Unit_ZX_A2L_01 "Copeland ZX*Y outdoor refrigeration units for A1 & A2L Applications – XCM25D Controller parameter list"	-	Adjust to application requirements

Defrost with evaporator fan System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
A19	Probe 7 configuration	nu = Not used	Ept = Evaporator temperature
G12	Defrost probe selection	nu = Not used	Ept = Evaporator temperature
G23	Defrost interval mode	nu = Not used	In = By time (G18)
G42	Fans operating mode	Cn	Oy
S05	Relay output 2	nu = Not used	EPF = Evaporator fan
G18	Interval between defrost cycles	4 min	Adjust to application requirements
G19	Maximum duration of defrost	20 min	Adjust to application requirements
G21	Defrost termination temperature	10 °C	Adjust to application requirements
G26	Drip time	1 min	Adjust to application requirements
G55	Fan delay after defrost	1 min	Adjust to application requirements

Unit On/Off System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
R07	Digital input 3 configuration	nu = Not used	OnF = On/Off
R08	Digital input 3 polarity	CL = Closed	Adjust to application requirements

Evaporator fan System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
G42	Fans operating mode	cn	cn = Switch on and off with the compressor, stop during defrost On = Always on, stop during defrost cy = Switch on and off with the compressor, run during defrost Oy = Always on, run during defrost
S05	Relay output 2	nu = Not used	EpF = Evaporator fan
G45	Fan on time	1 min	Adjust to application requirements
G46	Fan off time	1 min	Adjust to application requirements
G55	Fan delay after defrost	1 min	Adjust to application requirements

System EXV System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
A19	Probe 7 configuration	nu = Not used	SLt = Suction line temp
L02	Set of superheating	5	7
S11	EXV configuration	uIn or LIn	SHt = System superheat

Door switch System restart is required!			
Parameter	Parameter description	Factory setting	Required setting
G08	Compressor and fan status with open door	Fn	nO = Normal operation Fn = Stop fan cP = Compressor off Fc = Compressor and fans off
R07	Digital input 3 configuration	nu = Not used	dOr = Door
G53	Maximum time with open door before alarm goes off	3 min	Adjust to application requirements
R08	Digital input 3 polarity	CL = Closed	Adjust to application requirements

Table 38: Additional features for customization

Appendix 7: Temperature / resistance curve for B7 Sensor (customer option)

R25 = 10 kΩ B25/85 = 3435 K

Temp. (C)	Resistance (kΩ)	Temp. (C)	Resistance (kΩ)	Temp. (C)	Resistance (kΩ)	Temp. (C)	Resistance (kΩ)	Temp. (C)	Resistance (kΩ)	Temp. (C)	Resistance (kΩ)
-50	329.2	-21	71.07	8	19.48	37	6.468	66	2.512	95	1.108
-49	310.7	-20	67.74	9	18.70	38	6.246	67	2.437	96	1.080
-48	293.3	-19	64.54	10	17.96	39	6.033	68	2.365	97	1.052
-47	277.0	-18	61.52	11	17.24	40	5.829	69	2.296	98	1.025
-46	261.3	-17	58.65	12	16.55	41	5.630	70	2.229	99	0.999
-45	247.5	-16	55.95	13	15.90	42	5.439	71	2.163	100	0.974
-44	234.1	-15	53.39	14	15.28	43	5.256	72	2.101	101	0.949
-43	221.6	-14	50.95	15	14.68	44	5.080	73	2.040	102	0.925
-42	209.8	-13	48.66	16	14.12	45	4.912	74	1.981	103	0.902
-41	198.7	-12	46.48	17	13.57	46	4.749	75	1.924	104	0.879
-40	188.4	-11	44.44	18	13.06	47	4.594	76	1.870	105	0.858
-39	178.3	-10	42.45	19	12.56	48	4.444	77	1.817	106	0.836
-38	168.9	-9	40.56	20	12.09	49	4.300	78	1.766	107	0.816
-37	160.1	-8	38.76	21	11.63	50	4.161	79	1.716	108	0.796
-36	151.8	-7	37.05	22	11.20	51	4.026	80	1.669	109	0.777
-35	144.0	-6	35.43	23	10.78	52	3.897	81	1.622	110	0.758
-34	136.6	-5	33.89	24	10.38	53	3.772	82	1.577	111	0.740
-33	129.7	-4	32.43	25	10.00	54	3.652	83	1.534	112	0.722
-32	123.2	-3	31.04	26	9.632	55	3.537	84	1.492	113	0.705
-31	117.1	-2	29.72	27	9.281	56	3.426	85	1.451	114	0.688
-30	111.3	-1	28.47	28	8.944	57	3.319	86	1.412	115	0.672
-29	105.7	0	27.28	29	8.622	58	3.216	87	1.374	116	0.656
-28	100.4	1	26.13	30	8.313	59	3.116	88	1.337	117	0.641
-27	95.47	2	25.03	31	8.015	60	3.021	89	1.301	118	0.626
-26	90.80	3	23.99	32	7.725	61	2.928	90	1.266	119	0.611
-25	86.39	4	22.99	33	7.455	62	2.838	91	1.233	120	0.597
-24	82.22	5	22.05	34	7.192	63	2.752	92	1.200		
-23	78.29	6	21.15	35	6.941	64	2.669	93	1.169		
-22	74.58	7	20.30	36	6.699	65	2.589	94	1.138		

Table 39: B7 A17 optional sensor >> Temperature / resistance curve

Appendix 8: List of tables and figures

Tables

Table 1: ZX*Y refrigeration unit technical data.....	4
Table 2: ZX*Y refrigeration unit features.....	4
Table 3: Qualified refrigerants and oils.....	6
Table 4: PED category based on refrigerant used.....	7
Table 5: BOM.....	7
Table 6: Legend of the P&I diagram for ZXMY units.....	8
Table 7: Legend of the P&I diagram for ZXDY units.....	9
Table 8: Legend of the P&I diagram for ZXLY units.....	10
Table 9: Compressor models cross reference.....	11
Table 10: Condenser fans technical data.....	11
Table 11: Pre-arranged additional connections.....	14
Table 12: Digital output specifications.....	15
Table 13: External room thermostat – Parameters.....	15
Table 14: External temperature sensor – Parameters.....	16
Table 15: Discharge pressure limitations.....	16
Table 16: Defrost parameters.....	18
Table 17: LED functions description.....	19
Table 18: Display visualisation.....	19
Table 19: Single commands.....	20
Table 20: Double commands.....	21
Table 21: Programming level 1 parameters.....	21
Table 22: Fast access menu.....	22
Table 23: Parameters in programming level Pr1.....	23
Table 24: Minimum cut-out value for pumpdown.....	25
Table 25: Pumpdown 1.....	25
Table 26: Pumpdown 2.....	25
Table 27: Internal pumpdown with temperature sensor.....	26
Table 28: How to check the alarm list.....	28
Table 29: Weights.....	30
Table 30: Piping connection sizes.....	31
Table 31: Maximum distances between 2 clamp supports.....	31
Table 32: Unit maximum rated currents for cable selection.....	36
Table 33: Main fuse settings.....	38
Table 34: PRV minimum requirements.....	39
Table 35: Overview of the ZX*Y unit components.....	52
Table 36: Parameters level 1.....	55
Table 37: Alarm code overview.....	59
Table 38: Additional features for customization.....	63
Table 39: B7 A17 optional sensor >> Temperature / resistance curve.....	64

Figures

Figure 1: Dimensions of models ZXMY-020E to ZXMY-040E, ZXDY-030E and ZXLY-020E to ZXLY-040E (single-fan units).....	5
Figure 2: Dimensions of models ZXMY-050E to ZXMY-075E, ZXDY-040E to ZXDY-075E and ZXLY-050E to ZXLY-075E (dual-fan units).....	5
Figure 3: Nomenclature ZX*Y units.....	6
Figure 4: P&I diagram for ZXMY units.....	8
Figure 5: P&I diagram for ZXDY units.....	9
Figure 6: P&I diagram for ZXLY units.....	10
Figure 7: ZX*Y unit housing.....	11
Figure 8: XCM25D Electronic controller.....	12
Figure 9: XCM25D controller functionality overview.....	13
Figure 10: Modbus port and termination jumpers.....	13
Figure 11: Pre-arranged additional connections.....	15
Figure 12: External temperature sensor – Functionality.....	16
Figure 13: Local display.....	19
Figure 14: Remote display front panel mounting.....	20
Figure 15: VNR connection for the remote display.....	20
Figure 16: Digital operation.....	24
Figure 17: Pumpdown functionality with temperature sensor.....	26
Figure 18: Copeland Controls Hot Key.....	27

Figure 19: Location of Hot Key plug connection	27
Figure 20: Maximum stacking loads for transport and storage	30
Figure 21: Brazing – Sectional view	32
Figure 22: Suction tube brazing areas	33
Figure 23: Ground connection on top cover, right cover and divider.....	34
Figure 24: Ground connection on right cover and baseplate	34
Figure 25: Ground connection on fan bracket and base plate	34
Figure 26: Ground connection on door	35
Figure 27: Ground connection on condenser.....	35
Figure 28: Ground connection in electrical cabinet	35
Figure 29: Circuit breaker with overcurrent protection	38
Figure 30: Top cover of ZX*Y refrigeration units	39
Figure 31: Access to PRV port.....	39
Figure 32: PRV port without plug	39
Figure 33: Example of pressure relief valve and discharge pipe configuration.....	40
Figure 34: Fixing dimensions and distances – Single-fan units	40
Figure 35: Fixing dimensions and distances – Dual-fan units.....	41
Figure 36: Service valves for refrigerant charging	43
Figure 37: Tube connecting areas	47
Figure 38 Figure 39 Figure 40 Figure 41	48
Figure 42: Visual inspection of the rubber gasket	49
Figure 43: Wiring diagram – ZXMY & ZXLY units	53
Figure 44: Wiring diagram – ZXDY units.....	54

DISCLAIMER: The Copeland logo is a trademark and service mark of Copeland LP or one of its affiliates. Copeland Europe GmbH shall not be liable for errors in the stated capacities, dimensions, etc., as well as typographic errors. Products, specifications, assumptions, designs and technical data contained in this document are subject to modification by us without prior notice. Illustrations are not binding. ©2024 Copeland LP. All rights reserved.

BENELUX

Josephinastraat 19
NL-6462 EL Kerkrade
Tel: +31 45 535 06 73
Fax: +31 45 535 06 71
benelux.sales@copeland.com

GERMANY, AUSTRIA & SWITZERLAND

Theo-Mack-Str. 3
DE-63477 Maintal
Tel: +49 6109 605 90
cde.sales@copeland.com

FRANCE, GREECE & MAGHREB

8, Allée du Moulin Berger
FR-69134 Ecully Cédex,
Technoparc - CS 90220
Tel: +33 4 78 66 85 70
Fax: +33 4 78 66 85 71
mediterranean.sales@copeland.com

ITALY

Via Ramazzotti, 26
IT-21047 Saronno (VA)
Tel: + 39 02 9713 8060
Fax: +39 02 96 17 88 88
italy.sales@copeland.com

SPAIN & PORTUGAL

C/ Pujades, 51-55 Box 53
ES-08005 Barcelona
Tel: +34 93 412 37 52
iberica.sales@copeland.com

CZECH REPUBLIC

Hajkova 22
CZ - 133 00 Prague
Tel: +420 733 161 651
Fax: +420 271 035 655
Pavel.Sudek@copeland.com

ROMANIA & BULGARIA

Str. Alexandru Vaida Voevod Nr. 53B, Et. 5
400436, Cluj-Napoca, Romania
Tel: +40 364 821 680
ro-bg.sales@copeland.com

ASIA PACIFIC

Suite 2503-8, 25/F., Exchange Tower
33 Wang Chiu Road, Kowloon Bay
Kowloon, Hong Kong
Tel: +852 2866 3108
Fax: +852 2520 6227

UK & IRELAND

Tel: +44 1189 83 80 00
Fax: +44 1189 83 80 01
uk.sales@copeland.com

SWEDEN, DENMARK, NORWAY & FINLAND

Pascalstr. 65
DE-52076 Aachen
Tel: +49 2408 929 0
Fax: +49 2408 929 525
nordic.sales@copeland.com

EASTERN EUROPE & TURKEY

Pascalstr. 65
DE-52076 Aachen
Tel: +49 2408 929 0
Fax: +49 2408 929 525
easterneurope.sales@copeland.com

POLAND

ul. Konstruktorska 13
PL-02673 Warsaw
Tel: +48 22 458 92 05
Fax: +48 22 458 92 55
poland.sales@copeland.com

BALKAN

Selska cesta 93
HR-10 000 Zagreb
Tel: +385 1 560 38 75
Fax: +385 1 560 38 79
balkan.sales@copeland.com

MIDDLE EAST & AFRICA

PO Box 26382
Jebel Ali Free Zone - South, Dubai - UAE
Tel: +971 4 811 81 00
Fax: +971 4 886 54 65
mea.sales@copeland.com

For more details, see copeland.com/en-gb

Copeland Europe GmbH
Pascalstrasse 65 - 52076 Aachen, Germany
Tel. +49 (0) 2408 929 0 - Fax: +49 (0) 2408 929 570 - Internet: copeland.com/en-gb

The Copeland logo is a trademark and service mark of Copeland LP or one of its affiliates. Copeland Europe GmbH shall not be liable for errors in the stated capacities, dimensions, etc., as well as typographic errors. Products, specifications, assumptions, designs and technical data contained in this document are subject to modification by us without prior notice. Illustrations are not binding. ©2024 Copeland LP. All rights reserved.

COPELAND